


# HP ProLiant SL160z G6 Server

## Maintenance and Service Guide



**Legal notices**

© Copyright 2010, 2011 Hewlett-Packard Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Intel, Xeon, and Pentium are trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

---

# Contents

Customer self repair .....	5
Parts only warranty service .....	5
Illustrated parts catalog .....	16
Mechanical components .....	16
System components .....	20
HP Contact Information .....	23
Before You Contact HP .....	24
Removal and Replacement Procedures .....	25
Hardware Configuration Tools .....	25
Hardware Configuration Information .....	25
Electrostatic Discharge Information .....	25
Pre-Installation Procedure .....	26
Post-installation instructions .....	26
Server Warnings and Cautions .....	26
Symbols on Equipment .....	27
Powering Down the Server .....	28
System Covers .....	28
Top Cover .....	28
Cable Management .....	29
Cable Connections .....	30
Hard Drives .....	31
System Board Configuration .....	33
Processor .....	33
Memory .....	40
PCI Expansion Cards .....	42
System Battery .....	48
System Board Removal and Replacement Procedure .....	50
Power Supply Unit (PSU) .....	52
System Fan .....	54
Connectors, Switches, and LEDs .....	56
Connectors and Components .....	56
Front Panel Components .....	56
Rear panel components .....	57
System board components .....	58
Jumpers –Password and Chassis ID .....	59
LED Indicators .....	60
Front panel LED indicators .....	60
Rear panel LED indicators .....	62
Diagnostic tools and Setup Utilities .....	64
BIOS Software .....	64
BIOS Setup Utility .....	64
Accessing the BIOS Setup Utility .....	64
Navigating through the Setup Utility .....	65
Setup Utility Menu Bar .....	66
BIOS Update .....	71
Clear CMOS .....	72

Power-on Self-Test (POST).....	72
POST Error Indicators .....	72
POST Errors Message Definition .....	73
POST Related Troubleshooting.....	74
Physical and Operating Specifications .....	75
System Unit .....	75
Index.....	78

---

# Customer self repair

HP products are designed with many Customer Self Repair (CSR) parts to minimize repair time and allow for greater flexibility in performing defective parts replacement. If during the diagnosis period HP (or HP service providers or service partners) identifies that the repair can be accomplished by the use of a CSR part, HP will ship that part directly to you for replacement. There are two categories of CSR parts:

- **Mandatory**—Parts for which customer self repair is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.
- **Optional**—Parts for which customer self repair is optional. These parts are also designed for customer self repair. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product.

**NOTE:** Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. These parts are identified as "No" in the Illustrated Parts Catalog.

Based on availability and where geography permits, CSR parts will be shipped for next business day delivery. Same day or four-hour delivery may be offered at an additional charge where geography permits. If assistance is required, you can call the HP Technical Support Center and a technician will help you over the telephone. HP specifies in the materials shipped with a replacement CSR part whether a defective part must be returned to HP. In cases where it is required to return the defective part to HP, you must ship the defective part back to HP within a defined period of time, normally five (5) business days. The defective part must be returned with the associated documentation in the provided shipping material. Failure to return the defective part may result in HP billing you for the replacement. With a customer self repair, HP will pay all shipping and part return costs and determine the courier/carrier to be used.

For more information about HP's Customer Self Repair program, contact your local service provider. For the North American program, refer to the HP website (<http://www.hp.com/go/selfrepair>).

## Parts only warranty service

Your HP Limited Warranty may include a parts only warranty service. Under the terms of parts only warranty service, HP will provide replacement parts free of charge.

For parts only warranty service, CSR part replacement is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.

# Réparation par le client (CSR)

Les produits HP comportent de nombreuses pièces CSR (Customer Self Repair = réparation par le client) afin de minimiser les délais de réparation et faciliter le remplacement des pièces défectueuses. Si pendant la période de diagnostic, HP (ou ses partenaires ou mainteneurs agréés) détermine que la réparation peut être effectuée à l'aide d'une pièce CSR, HP vous l'envoie directement. Il existe deux catégories de pièces CSR:

- **Obligatoire** - Pièces pour lesquelles la réparation par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.
- **Facultatif** - Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez à HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable à votre produit.

**REMARQUE:** Certaines pièces HP ne sont pas conçues pour permettre au client d'effectuer lui-même la réparation. Pour que la garantie puisse s'appliquer, HP exige que le remplacement de la pièce soit effectué par un Mainteneur Agréé. Ces pièces sont identifiées par la mention "Non" dans le Catalogue illustré.

Les pièces CSR sont livrées le jour ouvré suivant, dans la limite des stocks disponibles et selon votre situation géographique. Si votre situation géographique le permet et que vous demandez une livraison le jour même ou dans les 4 heures, celle-ci vous sera facturée. Pour bénéficier d'une assistance téléphonique, appelez le Centre d'assistance technique HP. Dans les documents envoyés avec la pièce de rechange CSR, HP précise s'il est nécessaire de lui retourner la pièce défectueuse. Si c'est le cas, vous devez le faire dans le délai indiqué, généralement cinq (5) jours ouvrés. La pièce et sa documentation doivent être retournées dans l'emballage fourni. Si vous ne retournez pas la pièce défectueuse, HP se réserve le droit de vous facturer les coûts de remplacement. Dans le cas d'une pièce CSR, HP supporte l'ensemble des frais d'expédition et de retour, et détermine la société de courses ou le transporteur à utiliser.

Pour plus d'informations sur le programme CSR de HP, contactez votre Mainteneur Agréé local. Pour plus d'informations sur ce programme en Amérique du Nord, consultez le site Web HP (<http://www.hp.com/go/selfrepair>).

## Service de garantie "pièces seules"

Votre garantie limitée HP peut inclure un service de garantie "pièces seules". Dans ce cas, les pièces de rechange fournies par HP ne sont pas facturées.

Dans le cadre de ce service, la réparation des pièces CSR par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.

# Riparazione da parte del cliente

Per abbreviare i tempi di riparazione e garantire una maggiore flessibilità nella sostituzione di parti difettose, i prodotti HP sono realizzati con numerosi componenti che possono essere riparati direttamente dal cliente (CSR, Customer Self Repair). Se in fase di diagnostica HP (o un centro di servizi o di assistenza HP) identifica il guasto come riparabile mediante un ricambio CSR, HP lo spedisce direttamente al cliente per la sostituzione. Vi sono due categorie di parti CSR:

- **Obbligatorie** – Parti che devono essere necessariamente riparate dal cliente. Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio.
- **Opzionali** – Parti la cui riparazione da parte del cliente è facoltativa. Si tratta comunque di componenti progettati per questo scopo. Se tuttavia il cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese aggiuntive a seconda del tipo di garanzia previsto per il prodotto.

**NOTA:** alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un "No" nel Catalogo illustrato dei componenti.

In base alla disponibilità e alla località geografica, le parti CSR vengono spedite con consegna entro il giorno lavorativo seguente. La consegna nel giorno stesso o entro quattro ore è offerta con un supplemento di costo solo in alcune zone. In caso di necessità si può richiedere l'assistenza telefonica di un addetto del centro di supporto tecnico HP. Nel materiale fornito con una parte di ricambio CSR, HP specifica se il cliente deve restituire dei componenti. Qualora sia richiesta la resa ad HP del componente difettoso, lo si deve spedire ad HP entro un determinato periodo di tempo, generalmente cinque (5) giorni lavorativi. Il componente difettoso deve essere restituito con la documentazione associata nell'imballo di spedizione fornito. La mancata restituzione del componente può comportare la fatturazione del ricambio da parte di HP. Nel caso di riparazione da parte del cliente, HP sostiene tutte le spese di spedizione e resa e sceglie il corriere/vettore da utilizzare.

Per ulteriori informazioni sul programma CSR di HP contattare il centro di assistenza di zona. Per il programma in Nord America fare riferimento al sito Web HP (<http://www.hp.com/go/selfrepair>).

## Servizio di garanzia per i soli componenti

La garanzia limitata HP può includere un servizio di garanzia per i soli componenti. Nei termini di garanzia del servizio per i soli componenti, HP fornirà gratuitamente le parti di ricambio.

Per il servizio di garanzia per i soli componenti è obbligatoria la formula CSR che prevede la riparazione da parte del cliente. Se il cliente invece richiede la sostituzione ad HP, dovrà sostenere le spese di spedizione e di manodopera per il servizio.

# Customer Self Repair

HP Produkte enthalten viele CSR-Teile (Customer Self Repair), um Reparaturzeiten zu minimieren und höhere Flexibilität beim Austausch defekter Bauteile zu ermöglichen. Wenn HP (oder ein HP Servicepartner) bei der Diagnose feststellt, dass das Produkt mithilfe eines CSR-Teils repariert werden kann, sendet Ihnen HP dieses Bauteil zum Austausch direkt zu. CSR-Teile werden in zwei Kategorien unterteilt:

- **Zwingend** – Teile, für die das Customer Self Repair-Verfahren zwingend vorgegeben ist. Wenn Sie den Austausch dieser Teile von HP vornehmen lassen, werden Ihnen die Anfahrt- und Arbeitskosten für diesen Service berechnet.
- **Optional** – Teile, für die das Customer Self Repair-Verfahren optional ist. Diese Teile sind auch für Customer Self Repair ausgelegt. Wenn Sie jedoch den Austausch dieser Teile von HP vornehmen lassen möchten, können bei diesem Service je nach den für Ihr Produkt vorgesehenen Garantiebedingungen zusätzliche Kosten anfallen.

**HINWEIS:** Einige Teile sind nicht für Customer Self Repair ausgelegt. Um den Garantieanspruch des Kunden zu erfüllen, muss das Teil von einem HP Servicepartner ersetzt werden. Im illustrierten Teilekatalog sind diese Teile mit „No“ bzw. „Nein“ gekennzeichnet.

CSR-Teile werden abhängig von der Verfügbarkeit und vom Lieferziel am folgenden Geschäftstag geliefert. Für bestimmte Standorte ist eine Lieferung am selben Tag oder innerhalb von vier Stunden gegen einen Aufpreis verfügbar. Wenn Sie Hilfe benötigen, können Sie das HP technische Support Center anrufen und sich von einem Mitarbeiter per Telefon helfen lassen. Den Materialien, die mit einem CSR-Ersatzteil geliefert werden, können Sie entnehmen, ob das defekte Teil an HP zurückgeschickt werden muss. Wenn es erforderlich ist, das defekte Teil an HP zurückzuschicken, müssen Sie dies innerhalb eines vorgegebenen Zeitraums tun, in der Regel innerhalb von fünf (5) Geschäftstagen. Das defekte Teil muss mit der zugehörigen Dokumentation in der Verpackung zurückgeschickt werden, die im Lieferumfang enthalten ist. Wenn Sie das defekte Teil nicht zurückschicken, kann HP Ihnen das Ersatzteil in Rechnung stellen. Im Falle von Customer Self Repair kommt HP für alle Kosten für die Lieferung und Rücksendung auf und bestimmt den Kurier-/Frachtdienst.

Weitere Informationen über das HP Customer Self Repair Programm erhalten Sie von Ihrem Servicepartner vor Ort. Informationen über das CSR-Programm in Nordamerika finden Sie auf der HP Website unter (<http://www.hp.com/go/selfrepair>).

## Parts-only Warranty Service (Garantieservice ausschließlich für Teile)

Ihre HP Garantie umfasst möglicherweise einen Parts-only Warranty Service (Garantieservice ausschließlich für Teile). Gemäß den Bestimmungen des Parts-only Warranty Service stellt HP Ersatzteile kostenlos zur Verfügung.

Für den Parts-only Warranty Service ist das CSR-Verfahren zwingend vorgegeben. Wenn Sie den Austausch dieser Teile von HP vornehmen lassen, werden Ihnen die Anfahrt- und Arbeitskosten für diesen Service berechnet.

# Reparaciones del propio cliente

Los productos de HP incluyen muchos componentes que el propio usuario puede reemplazar (*Customer Self Repair*, CSR) para minimizar el tiempo de reparación y ofrecer una mayor flexibilidad a la hora de realizar sustituciones de componentes defectuosos. Si, durante la fase de diagnóstico, HP (o los proveedores o socios de servicio de HP) identifica que una reparación puede llevarse a cabo mediante el uso de un componente CSR, HP le enviará dicho componente directamente para que realice su sustitución. Los componentes CSR se clasifican en dos categorías:

- **Obligatorio:** componentes para los que la reparación por parte del usuario es obligatoria. Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.
- **Opcional:** componentes para los que la reparación por parte del usuario es opcional. Estos componentes también están diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su sustitución, puede o no conllevar costes adicionales, dependiendo del tipo de servicio de garantía correspondiente al producto.

**NOTA:** Algunos componentes no están diseñados para que puedan ser reparados por el usuario. Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra "No" en el catálogo ilustrado de componentes.

Según la disponibilidad y la situación geográfica, los componentes CSR se enviarán para que lleguen a su destino al siguiente día laborable. Si la situación geográfica lo permite, se puede solicitar la entrega en el mismo día o en cuatro horas con un coste adicional. Si precisa asistencia técnica, puede llamar al Centro de asistencia técnica de HP y recibirá ayuda telefónica por parte de un técnico. Con el envío de materiales para la sustitución de componentes CSR, HP especificará si los componentes defectuosos deberán devolverse a HP. En aquellos casos en los que sea necesario devolver algún componente a HP, deberá hacerlo en el periodo de tiempo especificado, normalmente cinco días laborables. Los componentes defectuosos deberán devolverse con toda la documentación relacionada y con el embalaje de envío. Si no enviara el componente defectuoso requerido, HP podrá cobrarle por el de sustitución. En el caso de todas sustituciones que lleve a cabo el cliente, HP se hará cargo de todos los gastos de envío y devolución de componentes y escogerá la empresa de transporte que se utilice para dicho servicio.

Para obtener más información acerca del programa de Reparaciones del propio cliente de HP, póngase en contacto con su proveedor de servicios local. Si está interesado en el programa para Norteamérica, visite la página web de HP siguiente (<http://www.hp.com/go/selfrepair>).

## Servicio de garantía exclusivo de componentes

La garantía limitada de HP puede que incluya un servicio de garantía exclusivo de componentes. Según las condiciones de este servicio exclusivo de componentes, HP le facilitará los componentes de repuesto sin cargo adicional alguno.

Para este servicio de garantía exclusivo de componentes, es obligatoria la sustitución de componentes por parte del usuario (CSR). Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.

# Customer Self Repair

Veel onderdelen in HP producten zijn door de klant zelf te repareren, waardoor de reparatieduur tot een minimum beperkt kan blijven en de flexibiliteit in het vervangen van defecte onderdelen groter is. Deze onderdelen worden CSR-onderdelen (Customer Self Repair) genoemd. Als HP (of een HP Service Partner) bij de diagnose vaststelt dat de reparatie kan worden uitgevoerd met een CSR-onderdeel, verzendt HP dat onderdeel rechtstreeks naar u, zodat u het defecte onderdeel daarmee kunt vervangen. Er zijn twee categorieën CSR-onderdelen:

- **Verplicht:** Onderdelen waarvoor reparatie door de klant verplicht is. Als u HP verzoekt deze onderdelen voor u te vervangen, worden u voor deze service reiskosten en arbeidsloon in rekening gebracht.
- **Optioneel:** Onderdelen waarvoor reparatie door de klant optioneel is. Ook deze onderdelen zijn ontworpen voor reparatie door de klant. Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garanteservice voor het product.

**OPMERKING:** Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievoorwaarden moet het onderdeel door een geautoriseerde Service Partner worden vervangen. Deze onderdelen worden in de geïllustreerde onderdelencatalogus aangemerkt met "Nee".

Afhankelijk van de leverbaarheid en de locatie worden CSR-onderdelen verzonden voor levering op de eerstvolgende werkdag. Levering op dezelfde dag of binnen vier uur kan tegen meerkosten worden aangeboden, indien dit mogelijk is gezien de locatie. Indien assistentie gewenst is, belt u een HP Service Partner om via de telefoon technische ondersteuning te ontvangen. HP vermeldt in de documentatie bij het vervangende CSR-onderdeel of het defecte onderdeel aan HP moet worden geretourneerd. Als het defecte onderdeel aan HP moet worden teruggezonden, moet u het defecte onderdeel binnen een bepaalde periode, gewoonlijk vijf (5) werkdagen, retourneren aan HP. Het defecte onderdeel moet met de bijbehorende documentatie worden geretourneerd in het meegeleverde verpakkingsmateriaal. Als u het defecte onderdeel niet terugzendt, kan HP u voor het vervangende onderdeel kosten in rekening brengen. Bij reparatie door de klant betaalt HP alle verzendkosten voor het vervangende en geretourneerde onderdeel en kiest HP zelf welke koerier/transportonderneming hiervoor wordt gebruikt.

Neem contact op met een Service Partner voor meer informatie over het Customer Self Repair programma van HP. Informatie over Service Partners vindt u op de HP website (<http://www.hp.nl/services/servicepartners>).

## Garanteservice "Parts Only"

Het is mogelijk dat de HP garantie alleen de garanteservice "Parts Only" omvat. Volgens de bepalingen van de Parts Only garanteservice zal HP kosteloos vervangende onderdelen ter beschikking stellen.

Voor de Parts Only garanteservice is vervanging door CSR-onderdelen verplicht. Als u HP verzoekt deze onderdelen voor u te vervangen, worden u voor deze service reiskosten en arbeidsloon in rekening gebracht.

# Reparo feito pelo cliente

Os produtos da HP são projetados com muitas peças para reparo feito pelo cliente (CSR) de modo a minimizar o tempo de reparo e permitir maior flexibilidade na substituição de peças com defeito. Se, durante o período de diagnóstico, a HP (ou fornecedores/parceiros de serviço da HP) concluir que o reparo pode ser efetuado pelo uso de uma peça CSR, a peça de reposição será enviada diretamente ao cliente. Existem duas categorias de peças CSR:

- **Obrigatória** – Peças cujo reparo feito pelo cliente é obrigatório. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.
- **Opcional** – Peças cujo reparo feito pelo cliente é opcional. Essas peças também são projetadas para o reparo feito pelo cliente. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto.

**OBSERVAÇÃO:** Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca "No" (Não), no catálogo de peças ilustrado.

Conforme a disponibilidade e o local geográfico, as peças CSR serão enviadas no primeiro dia útil após o pedido. Onde as condições geográficas permitirem, a entrega no mesmo dia ou em quatro horas pode ser feita mediante uma taxa adicional. Se precisar de auxílio, entre em contato com o Centro de suporte técnico da HP para que um técnico o ajude por telefone. A HP especifica nos materiais fornecidos com a peça CSR de reposição se a peça com defeito deve ser devolvida à HP. Nos casos em que isso for necessário, é preciso enviar a peça com defeito à HP dentro do período determinado, normalmente cinco (5) dias úteis. A peça com defeito deve ser enviada com a documentação correspondente no material de transporte fornecido. Caso não o faça, a HP poderá cobrar a reposição. Para as peças de reparo feito pelo cliente, a HP paga todas as despesas de transporte e de devolução da peça e determina a transportadora/serviço postal a ser utilizado.

Para obter mais informações sobre o programa de reparo feito pelo cliente da HP, entre em contato com o fornecedor de serviços local. Para o programa norte-americano, visite o site da HP (<http://www.hp.com/go/selfrepair>).

## Serviço de garantia apenas para peças

A garantia limitada da HP pode incluir um serviço de garantia apenas para peças. Segundo os termos do serviço de garantia apenas para peças, a HP fornece as peças de reposição sem cobrar nenhuma taxa.

No caso desse serviço, a substituição de peças CSR é obrigatória. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.

## 顧客自己修理保証サービス

修理時間を短縮し、故障部品の交換における高い柔軟性を確保するために、HP製品には多数の顧客自己修理（CSR）部品があります。診断の際に、CSR部品を使用すれば修理ができるとHP（HPまたはHP正規保守代理店）が判断した場合、HPはその部品を直接、お客様に発送し、お客様に交換していただきます。CSR部品には以下の2通りがあります。

- 必須 - 顧客自己修理が必須の部品。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費がお客様に請求されます。
- 任意 - 顧客自己修理が任意である部品。この部品も顧客自己修理用です。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、お買い上げの製品に適用される保証サービス内容の範囲内においては、別途費用を負担していただくことなく保証サービスを受けることができます。

注：HP製品の一部の部品は、顧客自己修理用ではありません。製品の保証を継続するためには、HPまたはHP正規保守代理店による交換作業が必須となります。部品カタログには、当該部品が顧客自己修理除外品である旨が記載されています。

部品供給が可能な場合、地域によっては、CSR部品を翌営業日に届くように発送します。また、地域によっては、追加費用を負担いただくことにより同日または4時間以内に届くように発送することも可能な場合があります。サポートが必要なときは、HPの修理受付窓口に電話していただければ、技術者が電話でアドバイスします。交換用のCSR部品または同梱物には、故障部品をHPに返送する必要があるかどうかが表示されています。故障部品をHPに返送する必要がある場合は、指定期限内（通常は5営業日以内）に故障部品をHPに返送してください。故障部品を返送する場合は、届いた時の梱包箱に関連書類とともに入れてください。故障部品を返送しない場合、HPから部品費用が請求されます。顧客自己修理の際には、HPは送料および部品返送費を全額負担し、使用する宅配便会社や運送会社を指定します。

## 部品のみ保証サービス

HP保証サービスには、部品のみ保証サービスが適用される場合があります。このサービスでは、交換部品は無償で提供されます。

部品のみ保証サービスにおいては、CSR部品をお客様により交換作業していただくことが必須となります。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費はお客様の負担となります。

# 客户自行维修

HP 产品提供许多客户自行维修 (CSR) 部件，以尽可能缩短维修时间和在更换缺陷部件方面提供更大的灵活性。如果在诊断期间 HP（或 HP 服务提供商或服务合作伙伴）确定可以通过使用 CSR 部件完成维修，HP 将直接把该部件发送给您进行更换。有两类 CSR 部件：

- **强制性的** — 要求客户必须自行维修的部件。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。
- **可选的** — 客户可以选择是否自行维修的部件。这些部件也是为客户自行维修设计的。不过，如果您要求 HP 为您更换这些部件，则根据您的产品指定的保修服务类型，HP 可能收取或不再收取任何附加费用。

**注：**某些 HP 部件的设计并未考虑客户自行维修。为了满足客户保修的需要，HP 要求授权服务提供商更换相关部件。这些部件在部件图解目录中标记为“否”。

CSR 部件将在下一个工作日发运（取决于备货情况和允许的地理范围）。在允许的地理范围内，可在当天或四小时内发运，但要收取额外费用。如果需要帮助，您可以致电 HP 技术支持中心，将会有技术人员通过电话为您提供帮助。HP 会在随更换的 CSR 部件发运的材料中指明是否必须将有缺陷的部件返还给 HP。如果要求您将有缺陷的部件返还给 HP，那么您必须在规定期限内（通常是五 (5) 个工作日）将缺陷部件发给 HP。有缺陷的部件必须随所提供的发运材料中的相关文件一起返还。如果未能送还有缺陷的部件，HP 可能会要求您支付更换费用。客户自行维修时，HP 将承担所有相关运输和部件返回费用，并指定快递员/承运商。

有关 HP 客户自行维修计划的详细信息，请与您当地的服务提供商联系。有关北美地区的计划，请访问 HP 网站 (<http://www.hp.com/go/selfrepair>)。

## 仅部件保修服务

您的 HP 有限保修服务可能涉及仅部件保修服务。根据仅部件保修服务条款的规定，HP 将免费提供更换的部件。

仅部件保修服务要求进行 CSR 部件更换。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。

# 客戶自行維修

HP 產品設計了許多「客戶自行維修」(CSR) 的零件以減少維修時間，並且使得更換瑕疵零件時能有更大的彈性。如果在診斷期間 HP (或 HP 服務供應商或維修夥伴) 辨認出此項維修工作可以藉由使用 CSR 零件來完成，則 HP 將直接寄送該零件給您作更換。CSR 零件分為兩種類別：

- **強制的** — 客戶自行維修所使用的零件是強制性的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。
- **選購的** — 客戶自行維修所使用的零件是選購的。這些零件也設計用於客戶自行維修之用。不過，如果您要求 HP 為您更換，則可能需要也可能不需要負擔額外的費用，端視針對此產品指定的保固服務類型而定。

**備註：**某些 HP 零件沒有消費者可自行維修的設計。為符合客戶保固，HP 需要授權的服務供應商更換零件。這些零件在圖示的零件目錄中，被標示為「否」。

基於材料取得及環境允許的情況下，CSR 零件將於下一個工作日以快遞寄送。在環境的允許下當天或四小時內送達，則可能需要額外的費用。若您需要協助，可致電「HP 技術支援中心」，會有一位技術人員透過電話來協助您。不論損壞的零件是否必須退回，HP 皆會在與 CSR 替換零件一起運送的材料中註明。若要將損壞的零件退回 HP，您必須在指定的一段時間內（通常為五 (5) 個工作天），將損壞的零件寄回 HP。損壞的零件必須與寄送資料中隨附的相關技術文件一併退還。如果無法退還損壞的零件，HP 可能要向您收取替換費用。針對客戶自行維修情形，HP 將負責所有運費及零件退還費用並指定使用何家快遞/貨運公司。

如需 HP 的「客戶自行維修」方案詳細資訊，請連絡您當地的服務供應商。至於北美方案，請參閱 HP 網站 (<http://www.hp.com/go/selfrepair>)。

## 僅限零件的保固服務

您的「HP 有限保固」可能包含僅限零件的保固服務。在僅限零件的保固服務情況下，HP 將免費提供替換零件。

針對僅限零件的保固服務，CSR 零件替換是強制性的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。

## 고객 셀프 수리

HP 제품은 수리 시간을 최소화하고 결함이 있는 부품 교체 시 더욱 융통성을 발휘할 수 있도록 하기 위해 고객 셀프 수리(CSR) 부품을 다량 사용하여 설계되었습니다. 진단 기간 동안 HP(또는 HP 서비스 공급업체 또는 서비스 협력업체)에서 CSR 부품을 사용하여 수리가 가능하다고 판단되면 HP는 해당 부품을 바로 사용자에게 보내어 사용자가 교체할 수 있도록 합니다. CSR 부품에는 두 가지 종류가 있습니다.

- **고객 셀프 수리가 의무 사항인 필수 부품.** 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.
- **고객 셀프 수리가 선택 사항인 부품.** 이 부품들도 고객 셀프 수리가 가능하도록 설계되었습니다. 하지만 사용자가 HP에 이 부품의 교체를 요청할 경우 사용자가 구입한 제품에 해당하는 보증 서비스 유형에 따라 추가 비용 없이 교체가 가능할 수 있습니다.

**참고:** 일부 HP 부품은 고객 셀프 수리가 불가능하도록 설계되었습니다. HP는 만족스러운 고객 보증을 위해 공인 서비스 제공업체를 통해 부품을 교체하도록 하고 있습니다. 이러한 부품들은 Illustrated Parts Catalog에 "No"라고 표시되어 있습니다.

CSR 부품은 재고 상태와 지리적 조건이 허용하는 경우 다음 영업일 납품이 가능하도록 배송이 이루어집니다. 지리적 조건이 허용하는 경우 추가 비용이 청구되는 조건으로 당일 또는 4시간 배송이 가능할 수도 있습니다. 도움이 필요하시면 HP 기술 지원 센터로 전화하십시오. 전문 기술자가 전화로 도움을 줄 것입니다. HP는 결함이 발생한 부품을 HP로 반환해야 하는지 여부를 CSR 교체 부품과 함께 배송된 자료에 지정합니다. 결함이 발생한 부품을 HP로 반환해야 하는 경우에는 지정된 기간 내(통상 영업일 기준 5일)에 HP로 반환해야 합니다. 이 때 결함이 발생한 부품은 제공된 포장 재료에 넣어 관련 설명서와 함께 반환해야 합니다. 결함이 발생한 부품을 반환하지 않는 경우 HP가 교체 부품에 대해 비용을 청구할 수 있습니다. 고객 셀프 수리의 경우, HP는 모든 운송 및 부품 반환 비용을 부담하며 이용할 운송업체 및 택배 서비스를 결정합니다.

HP 고객 셀프 수리 프로그램에 대한 자세한 내용은 가까운 서비스 제공업체에 문의하십시오. 북미 지역의 프로그램에 대해서는 HP 웹 사이트(<http://www.hp.com/go/selfrepair>)를 참조하십시오.


## 부품 제공 보증 서비스

HP 제한 보증에는 부품 제공 보증 서비스가 포함될 수 있습니다. 이러한 경우 HP는 부품 제공 보증 서비스의 조건에 따라 교체 부품만을 무료로 제공합니다.

부품 제공 보증 서비스 제공 시 CSR 부품 교체는 의무 사항입니다. 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.

# Illustrated parts catalog

## Mechanical components



Item	Description	Spare part number	Customer self repair
1	Top cover		Mandatory <sup>1</sup>
2	X16 riser card bracket		Mandatory <sup>1</sup>
3	1U tray for 160 system		Mandatory <sup>1</sup>
4	X4 riser card cage		Mandatory <sup>1</sup>
5	Fan blank kit		Mandatory
6	Power supply blank kit		Mandatory <sup>1</sup>

<sup>1</sup>Mandatory—Parts for which customer self repair is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.

<sup>2</sup>Optional—Parts for which customer self repair is optional. These parts are also designed for customer self repair. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product.

<sup>3</sup>No—Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. These parts are identified as "No" in the Illustrated Parts Catalog.

<sup>1</sup>Mandatory: Obligatoire—Pièces pour lesquelles la réparation par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.

<sup>2</sup>Optional: Facultatif—Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez à HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable à votre produit.

<sup>3</sup>No: Non—Certaines pièces HP ne sont pas conçues pour permettre au client d'effectuer lui-même la réparation. Pour que la garantie puisse s'appliquer, HP exige que le remplacement de la pièce soit effectué par un Mainteneur Agréé. Ces pièces sont identifiées par la mention "Non" dans le Catalogue illustré.

<sup>1</sup>Mandatory: Obbligatorie—Parti che devono essere necessariamente riparate dal cliente. Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio.

<sup>2</sup>Optional: Opzionali—Parti la cui riparazione da parte del cliente è facoltativa. Si tratta comunque di componenti progettati per questo scopo. Se tuttavia il cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese addizionali a seconda del tipo di garanzia previsto per il prodotto.

<sup>3</sup>No: Non CSR—Alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un "No" nel Catalogo illustrato dei componenti.

<sup>1</sup>Mandatory: Zwingend—Teile, die im Rahmen des Customer Self Repair Programms ersetzt werden müssen. Wenn Sie diese Teile von HP ersetzen lassen, werden Ihnen die Versand- und Arbeitskosten für diesen Service berechnet.

<sup>2</sup>Optional: Optional—Teile, für die das Customer Self Repair-Verfahren optional ist. Diese Teile sind auch für Customer Self Repair ausgelegt. Wenn Sie jedoch den Austausch dieser Teile von HP vornehmen lassen möchten, können bei diesem Service je nach den für Ihr Produkt vorgesehenen Garantiebedingungen zusätzliche Kosten anfallen.

<sup>3</sup>No: Kein—Einige Teile sind nicht für Customer Self Repair ausgelegt. Um den Garantieanspruch des Kunden zu erfüllen, muss das Teil von einem HP Servicepartner ersetzt werden. Im illustrierten Teilekatalog sind diese Teile mit „No“ bzw. „Nein“ gekennzeichnet.

<sup>1</sup>Mandatory: Obligatorio—componentes para los que la reparación por parte del usuario es obligatoria. Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.

<sup>2</sup>Optional: Opcional— componentes para los que la reparación por parte del usuario es opcional. Estos componentes también están diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su sustitución, puede o no conllevar costes adicionales, dependiendo del tipo de servicio de garantía correspondiente al producto.

<sup>3</sup>No: No—Algunos componentes no están diseñados para que puedan ser reparados por el usuario. Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios

autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra "No" en el catálogo ilustrado de componentes.

<sup>1</sup>Mandatory: Verplicht—Onderdelen waarvoor Customer Self Repair verplicht is. Als u HP verzoekt deze onderdelen te vervangen, komen de reiskosten en het arbeidsloon voor uw rekening.

<sup>2</sup>Optional: Optioneel—Onderdelen waarvoor reparatie door de klant optioneel is. Ook deze onderdelen zijn ontworpen voor reparatie door de klant. Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garanteservice voor het product.

<sup>3</sup>No: Nee—Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievoorwaarden moet het onderdeel door een geautoriseerde Service Partner worden vervangen. Deze onderdelen worden in de geïllustreerde onderdelencatalogus aangemerkt met "Nee".

<sup>1</sup>Mandatory: Obrigatória—Peças cujo reparo feito pelo cliente é obrigatório. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.

<sup>2</sup>Optional: Opcional—Peças cujo reparo feito pelo cliente é opcional. Essas peças também são projetadas para o reparo feito pelo cliente. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto.

<sup>3</sup>No: Nenhuma—Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca "No" (Não), no catálogo de peças ilustrado.

<sup>1</sup>Mandatory : 必須 - 顧客自己修理が必須の部品。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費がお客様に請求されます。

<sup>2</sup>Optional : 任意 - 顧客自己修理が任意である部品。この部品も顧客自己修理用です。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、お買い上げの製品に適用される保証サービス内容の範囲内においては、費用を負担していただくことなく保証サービスを受けることができます。

<sup>3</sup>No : 除外 - HP製品の一部の部品は、顧客自己修理用ではありません。製品の保証を継続するためには、HPまたはHP正規保守代理店による交換作業が必須となります。部品カタログには、当該部品が顧客自己修理除外品である旨が記載されています。

<sup>1</sup>Mandatory: 强制性的 — 要求客户必须自行维修的部件。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。

<sup>2</sup>Optional: 可选的 — 客户可以选择是否自行维修的部件。这些部件也是为客户自行维修设计的。不过，如果您要求 HP 为您更换这些部件，则根据为您的产品指定的保修服务类型，HP 可能收取或不再收取任何附加费用。

<sup>3</sup>No: 否 — 某些 HP 部件的设计并未考虑客户自行维修。为了满足客户保修的需要，HP 要求授权服务提供商更换相关部件。这些部件在部件图解目录中标记为“否”。

<sup>1</sup>Mandatory: 強制的 — 客戶自行維修所使用的零件是強制的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。

<sup>2</sup>Optional: 選購的 — 客戶自行維修所使用的零件是選購的。這些零件也設計用於客戶自行維修之用。不過，如果您要求 HP 為您更換，則可能需要也可能不需要負擔額外的費用，端視針對此產品指定的保固服務類型而定。


<sup>3</sup>No: 否 — 某些 HP 零件沒有消費者可自行維修的設計。為符合客戶保固，HP 需要授權的服務供應商更換零件。這些零件在圖示的零件目錄中，被標示為「否」。

<sup>1</sup> Mandatory: 필수 — 고객 셀프 수리가 의무 사항인 필수 부품. 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.

<sup>2</sup> Optional: 옵션 — 고객 셀프 수리가 선택 사항인 부품. 이 부품들도 고객 셀프 수리가 가능하도록 설계되었습니다. 하지만 사용자가 HP에 이 부품의 교체를 요청할 경우 사용자가 구입한 제품에 해당하는 보증 서비스 유형에 따라 추가 비용 없이 교체가 가능할 수 있습니다.

<sup>3</sup> No: No — 고객 셀프 수리가 불가능하도록 설계된 HP 부품. 이 부품들은 고객 셀프 수리가 불가능하도록 설계되었습니다. HP는 고객 보증을 만족시키기 위해 공인 서비스 제공업체를 통해 부품을 교체하도록 하고 있습니다.

# System components



Item	Description	Spare Part Number	Customer Self Repair
1	System Fan	576898-001	Mandatory <sup>1</sup>
2a	SATA cable 1	576895-001	Mandatory <sup>1</sup>
2b	SATA cable 2	576895-001	Mandatory <sup>1</sup>
3	PCIe X16 riser card	536654-001	Optional <sup>2</sup>
4	Memory Module		Mandatory <sup>1</sup>
	DIMM 1GB PC3-10600E	501539-001	Mandatory <sup>1</sup>
	DIMM 2GB PC3-10600E	501540-001	Mandatory <sup>1</sup>
	DIMM 2GB PC3-10600R	501533-001	Mandatory <sup>1</sup>
	DIMM 4GB PC3-10600R	501534-001	Mandatory <sup>1</sup>
	DIMM 4GB PC3-8500R	501535-001	Mandatory <sup>1</sup>
	DIMM 8GB PC3-8500R	519201-001	Mandatory <sup>1</sup>
5	Processors		Optional <sup>2</sup>
	Intel Xeon 6c, 2.93 GHz, 12M, 95W	594882-001	Optional <sup>2</sup>
	Intel Xeon 6c, 2.8 GHz, 12M, 95W	586631-001	Optional <sup>2</sup>
	Intel Xeon 6c, 2.66 GHz, 12M, 95W	594884-001	Optional <sup>2</sup>
	Intel Xeon 4c, 2.66 GHz, 12M, 80W	594885-001	Optional <sup>2</sup>
	Intel Xeon 4c, 2.53 GHz, 12M, 80W	594886-001	Optional <sup>2</sup>

Item	Description	Spare Part Number	Customer Self Repair
	Intel Xeon 4c, 2.4 GHz, 12M, 80W	594887-001	Optional <sup>2</sup>
	Intel Xeon 6c, 2.4 GHz, 12M, 60W	594890-001	Optional <sup>2</sup>
	Intel Xeon 4c, 2.13 GHz, 12M, 40W	594891-001	Optional <sup>2</sup>
	Intel Xeon 2.13GHz/800/4M/4c/4.8 QPI/80W	506013-001	Optional <sup>2</sup>
	Intel Xeon 2.00GHz/800/4M/2c/4.8 QPI/80W	594889-001	Optional <sup>2</sup>
	Intel Xeon EP 2.26 GHz, 8M, 60W	504584-001	Optional <sup>2</sup>
	Intel Xeon EP L5506 2.13 GHz,4M, 60W	490070-001	Optional <sup>2</sup>
6	Processor Heat Sink	511803-001	Optional <sup>2</sup>
7	160 system board	519709-001	Optional <sup>2</sup>
8	PCIe X4 riser card	536654-001	Optional <sup>2</sup>
9	750w Power supply	511778-001	Mandatory <sup>1</sup>
10	Personality board to 160 board	576884-001	Mandatory <sup>1</sup>
11	AC power board	576882-001	Mandatory <sup>1</sup>
12	Front panel board, with cables*	607820-001	Mandatory <sup>1</sup>

\* Not shown

<sup>1</sup>Mandatory—Parts for which customer self repair is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.

<sup>2</sup>Optional—Parts for which customer self repair is optional. These parts are also designed for customer self repair. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product.

<sup>3</sup>No—Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. These parts are identified as "No" in the Illustrated Parts Catalog.

<sup>1</sup>Mandatory: Obligatoire—Pièces pour lesquelles la réparation par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.

<sup>2</sup>Optional: Facultatif—Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez à HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable à votre produit.

<sup>3</sup>No: Non—Certaines pièces HP ne sont pas conçues pour permettre au client d'effectuer lui-même la réparation. Pour que la garantie puisse s'appliquer, HP exige que le remplacement de la pièce soit effectué par un Mainteneur Agréé. Ces pièces sont identifiées par la mention "Non" dans le Catalogue illustré.

<sup>1</sup>Mandatory: Obbligatorie—Parti che devono essere necessariamente riparate dal cliente. Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio.

<sup>2</sup>Optional: Opzionali—Parti la cui riparazione da parte del cliente è facoltativa. Si tratta comunque di componenti progettati per questo scopo. Se tuttavia il cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese aggiuntive a seconda del tipo di garanzia previsto per il prodotto.

<sup>3</sup>No: Non CSR—Alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un "No" nel Catalogo illustrato dei componenti.

<sup>1</sup>Mandatory: Zwingend—Teile, die im Rahmen des Customer Self Repair Programms ersetzt werden müssen. Wenn Sie diese Teile von HP ersetzen lassen, werden Ihnen die Versand- und Arbeitskosten für diesen Service berechnet.

<sup>2</sup>Optional: Optional—Teile, für die das Customer Self Repair-Verfahren optional ist. Diese Teile sind auch für Customer Self Repair ausgelegt. Wenn Sie jedoch den Austausch dieser Teile von HP vornehmen lassen möchten, können bei diesem Service je nach den für Ihr Produkt vorgesehenen Garantiebedingungen zusätzliche Kosten anfallen.

<sup>3</sup>No: Kein—Einige Teile sind nicht für Customer Self Repair ausgelegt. Um den Garantieanspruch des Kunden zu erfüllen, muss das Teil von einem HP Servicepartner ersetzt werden. Im illustrierten Teilekatalog sind diese Teile mit „No“ bzw. „Nein“ gekennzeichnet.

<sup>1</sup>Mandatory: Obligatorio—componentes para los que la reparación por parte del usuario es obligatoria. Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.

<sup>2</sup>Optional: Opcional— componentes para los que la reparación por parte del usuario es opcional. Estos componentes también están diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su sustitución, puede o no conllevar costes adicionales, dependiendo del tipo de servicio de garantía correspondiente al producto.

<sup>3</sup>No: No—Algunos componentes no están diseñados para que puedan ser reparados por el usuario. Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra "No" en el catálogo ilustrado de componentes.

<sup>1</sup>Mandatory: Verplicht—Onderdelen waarvoor Customer Self Repair verplicht is. Als u HP verzoekt deze onderdelen te vervangen, komen de reiskosten en het arbeidsloon voor uw rekening.

<sup>2</sup>Optional: Optioneel—Onderdelen waarvoor reparatie door de klant optioneel is. Ook deze onderdelen zijn ontworpen voor reparatie door de klant. Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garantieservice voor het product.

<sup>3</sup>No: Nee—Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievoorwaarden moet het onderdeel door een geautoriseerde Service Partner worden vervangen. Deze onderdelen worden in de geïllustreerde onderdelencatalogus aangemerkt met "Nee".

<sup>1</sup>Mandatory: Obrigatória—Peças cujo reparo feito pelo cliente é obrigatório. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.

<sup>2</sup>Optional: Opcional—Peças cujo reparo feito pelo cliente é opcional. Essas peças também são projetadas para o reparo feito pelo cliente. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto.

<sup>3</sup>No: Nenhuma—Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca “No” (Não), no catálogo de peças ilustrado.

<sup>1</sup>Mandatory : 必須 - 顧客自己修理が必須の部品。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費がお客様に請求されます。

<sup>2</sup>Optional : 任意 - 顧客自己修理が任意である部品。この部品も顧客自己修理由です。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、お買い上げの製品に適用される保証サービス内容の範囲内においては、費用を負担していただくことなく保証サービスを受けることができます。

<sup>3</sup>No : 除外 - HP製品の一部の部品は、顧客自己修理由ではありません。製品の保証を継続するためには、HPまたはHP正規保守代理店による交換作業が必須となります。部品カタログには、当該部品が顧客自己修理除外品である旨が記載されています。

<sup>1</sup>Mandatory: 强制性的 — 要求客户必须自行维修的部件。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。

<sup>2</sup>Optional: 可选的 — 客户可以选择是否自行维修的部件。这些部件也是为客户自行维修设计的。不过，如果您要求 HP 为您更换这些部件，则根据为您的产品指定的保修服务类型，HP 可能收取或不再收取任何附加费用。

<sup>3</sup>No: 否 — 某些 HP 部件的设计并未考虑客户自行维修。为了满足客户保修的需要，HP 要求授权服务提供商更换相关部件。这些部件在部件图解目录中标记为“否”。

<sup>1</sup>Mandatory: 強制的 — 客戶自行維修所使用的零件是強制的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。

<sup>2</sup>Optional: 選購的 — 客戶自行維修所使用的零件是選購的。這些零件也設計用於客戶自行維修之用。不過，如果您要求 HP 為您更換，則可能需要也可能不需要負擔額外的費用，端視針對此產品指定的保固服務類型而定。

<sup>3</sup>No: 否 — 某些 HP 零件沒有消費者可自行維修的設計。為符合客戶保固，HP 需要授權的服務供應商更換零件。這些零件在圖示的零件目錄中，被標示為「否」。

<sup>1</sup> Mandatory: 필수 — 고객 셀프 수리가 의무 사항인 필수 부품. 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.

<sup>2</sup> Optional: 옵션 — 고객 셀프 수리가 선택 사항인 부품. 이 부품들도 고객 셀프 수리가 가능하도록 설계되었습니다. 하지만 사용자가 HP에 이 부품의 교체를 요청할 경우 사용자가 구입한 제품에 해당하는 보증 서비스 유형에 따라 추가 비용 없이 교체가 가능할 수 있습니다.

<sup>3</sup> No: No — 고객 셀프 수리가 불가능하도록 설계된 HP 부품. 이 부품들은 고객 셀프 수리가 불가능하도록 설계되었습니다. HP는 고객 보증을 만족시키기 위해 공인 서비스 제공업체를 통해 부품을 교체하도록 하고 있습니다.

## HP Contact Information

For the name of the nearest HP authorized reseller:

- In the United States, call 1-800-345-1518.
- In Canada, call 1-800-263-5868.
- In other locations, refer to the HP website at <http://www.hp.com/>.

For HP technical support:

- In North America:

- Call 1-800-HP-INVENT (1-800-474-6836). This service is available 24 hours a day, 7 days a week. For continuous quality improvement, calls may be recorded or monitored.
- If you have purchased a Care Pack (service upgrade), call 1-800-633-3600. For more information about Care Packs, refer to the HP website at <http://www.hp.com/>.
- Outside North America, call the nearest HP Technical Support Phone Center. For telephone numbers for worldwide Technical Support Centers, refer to the HP website at <http://www.hp.com/>.

## Before You Contact HP

Be sure to have the following information available before you call HP:

- Technical support registration number (if applicable)
- Product serial number
- Product model name and number
- Applicable error messages
- Add-on boards or hardware
- Third-party hardware or software
- Operating system type and revision level

---

# Removal and Replacement Procedures

This chapter provides subassembly/module-level removal and replacement procedures for the HP ProLiant SL160z G6 server.

Review the specifications of a new component before installing it to make sure it is compatible with the server. When you integrate new components into the system, record its model and serial number, and any other pertinent information for future reference. After completing any removal or replacement procedure, run the diagnostics program to verify that all components operate properly.

---

**NOTE:** The figures used in this chapter to illustrate procedural steps are labeled numerically (i.e., 1, 2...). When these figures are used in substep items, the alphabetically labeled instructions correspond to the numbered labels on the related figure (i.e., label 1 corresponds to step a, label 2 corresponds to step b, etc.). The procedures described in this section assume that the server is out of the rack and is positioned on a flat, stable surface.

---

## Hardware Configuration Tools

You need the following items for some procedures:

- T-10/T-15 wrench

The following references and software tools may also be used:

- HP ProLiant SL160z G6 Server Support CD
- IPMI Event Log
- Diagnostics Software

## Hardware Configuration Information

### Electrostatic Discharge Information

An electrostatic discharge (ESD) can damage static-sensitive devices or microcircuit. Proper packaging and grounding techniques are necessary precautions to prevent damage. To prevent electrostatic damage, observe the following precautions:

- Transport products in static-safe containers such as conductive tubes, bags, or boxes.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free stations.
- Cover workstations with approved static-dissipating material. Use a wrist strap connected to the work surface, and properly grounded (earthed) tools and equipment.
- Keep work area free of nonconductive materials, such as ordinary plastic assembly aids and foam packing.
- Make sure that you are always properly grounded (earthed) when touching a static-sensitive component or assembly.
- Avoid touching pins, leads, or circuitry.
- Always place drives with the Printed Circuit Board (PCB) assembly-side down.
- Use conductive field service tools.

## Pre-Installation Procedure

Perform the steps below before you open the server or before you remove or replace any component.



**WARNING:** Failure to properly turn off the server before you open the server or before you start installing/ removing components may cause serious damage as well as bodily harm.

1. Turn off the server and all the peripherals connected to it.
2. Unplug all cables from the power outlets to avoid exposure to high energy levels that may cause burns when parts are short-circuited by metal objects such as tools or jewelry.  
If necessary, label each one to expedite reassembly.
3. Disconnect telecommunication cables to avoid exposure to shock hazard from ringing voltages.
4. If server is installed in a rack, remove server and place it on a flat surface.
5. Remove the top cover according to the instructions described in the System Covers section in this chapter.
6. Remove the top middle cover according to the instructions described in the System Covers section in this chapter.
7. Follow the ESD precautions listed previously in this chapter when handling a server component.



**IMPORTANT:** To streamline the configuration process, read through the entire installation/removal procedure first and make sure you understand them before you begin.

## Post-installation instructions

Observe the following items after installing or removing a server component:

1. Be sure all components are installed according to the described step-by-step instructions.
2. Reinstall the rear cage, air baffle, peripherals, and system cables that you have removed.
3. Reinstall the top cover.
4. Reinstall server into rack.
5. Connect all external cables and the AC power cord to the system.
6. Press the power button on the front panel to turn on the server.

**NOTE:** The HP ProLiant SL160z G6 server supports up to 2 750-W power supply units, but 1 power supply only supports 2 nodes of the sever and 2 power supply supports 4 nodes of the sever.

## Server Warnings and Cautions

Before installing a server, be sure that you understand the following warnings and cautions.



**WARNING:** To reduce the risk of electric shock or damage to the equipment:

- Do not disable the power cord grounding plug. The grounding plug is an important safety feature.
- Plug the power cord into a grounded (earthed) electrical outlet that is easily accessible at all times.
- Unplug the power cord from the power supply to disconnect power to the equipment.
- Do not route the power cord where it can be walked on or pinched by items placed against it. Pay particular attention to the plug, electrical outlet, and the point where the cord extends from the server.

---

**⚠ WARNING:** To reduce the risk of personal injury from hot surfaces, allow the drives and the internal system components to cool before touching them.

---

**⚠ CAUTION:** Do not operate the server for long periods with the access panel open or removed. Operating the server in this manner results in improper airflow and improper cooling that can lead to thermal damage.

---

**⚠ CAUTION:** The following rack-mount instructions shall be paid attention to.

- Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T<sub>ma</sub>) specified by the manufacturer.
  - Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.
  - Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
  - Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
  - Reliable Earthing - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips)."
- 

## Symbols on Equipment

The following symbols may be placed on equipment to indicate the presence of potentially hazardous conditions.



---

This symbol indicates the presence of hazardous energy circuits or electric shock hazards. Refer all servicing to qualified personnel.

**WARNING:** To reduce the risk of injury from electric shock hazards, do not open this enclosure. Refer all maintenance, upgrades, and servicing to qualified personnel.

---



This symbol indicates the presence of electric shock hazards. The area contains no user or field serviceable parts. Do not open for any reason.

**WARNING:** To reduce the risk of injury from electric shock hazards, do not open this enclosure.

---



This symbol on an RJ-45 receptacle indicates a network interface connection.

**WARNING:** To reduce the risk of electric shock, fire, or damage to the equipment, do not plug telephone or telecommunications connectors into this receptacle.

---



---

This symbol indicates the presence of a hot surface or hot component. If this surface is contacted, the potential for injury exists.

**WARNING:** To reduce the risk of injury from a hot component, allow the surface to cool before touching.

---



weight1\_kg  
weight1\_lb

This symbol indicates that the component exceeds the recommended weight for one individual to handle safely.

**WARNING:** To reduce the risk of personal injury or damage to the equipment, observe local occupational health and safety requirements and guidelines for manual material handling.

---



These symbols, on power supplies or systems, indicate that the equipment is supplied by multiple sources of power.

**WARNING:** To reduce the risk of injury from electric shock, remove all power cords to completely disconnect power from the system.

---

## Powering Down the Server

The server does not completely power down when the power button on the front panel is pressed. The button toggles between On and Standby. The standby position removes power from most electronics and the drives, but some internal circuitry remains active. To completely remove all power from the system, disconnect all power cords from the server.

To power down the server:

1. Shut down server as directed by the operating system documentation.
2. Press the power button to toggle to Standby.

This places the server in standby mode changing the power LED indicator to amber. In this mode, the main power supply output is disabled. Standby does not completely disable or remove power from the system.

3. Disconnect the AC power cord from the AC outlet and then from the server.
4. Be sure that the power LED indicator is turned off and that the fan noise has stopped.
5. Disconnect all external peripheral devices from the server.

## System Covers


The top cover is detachable for system fans and AC power board maintenance. If you need to repair or replace a server component, it's unnecessary to remove the top cover.

### Top Cover

**To remove the top cover:**

1. Remove the screw securing the top cover to the chassis.
2. Slide the top cover and then lift them away from away from the chassis.


**Figure 1** Removing the top cover



**To reinstall the top cover:**

1. Align the top cover to the chassis and then slide it towards the front panel to position it into place.
2. Fasten the two rear screws to secure the top cover to the chassis.

**Figure 2** Reinstalling the top cover



## Cable Management

Always follow good cable management practices when working inside the computer.

- Keep cables away from major heat sources like the heat sink.
- Do not jam cables on top of expansion cards or memory modules. Printed circuit cards are not designed to withstand excessive pressure.
- Keep cables clear of sliding or moveable parts to prevent cutting or crimping.


- When folding a flat ribbon cable, never fold to a sharp crease. Sharp creases may damage the wires.
- Some flat ribbon cables come pre-folded. Never change the folds on these cables.
- Do not sharply bend any cable. A sharp bend can break the internal wires.
- Never bend a SATA data cable tighter than a 30 mm (1.18 in) radius.
- Never crease a SATA data cable.
- Do not rely on components like the drive cage, power supply, or system cover to push cables down into the chassis.

Removing power supply cables from the system board connectors (J36) follow below steps:

1. Squeeze on the top of the retaining latch attached to the cable end of the connector.
2. Grasp the cable end of the connector and pull it straight up.

**△ CAUTION:** Always pull the connector - NEVER pull on the cable. Pulling on the cable could damage the cable and result in a failed power supply.

**Figure 3** Unplugging power cables



## Cable Connections

The following table provides information about switching power supply cable connector labels.

**Table 1** Power BP Cable connections

Cable	To	Cable Designator
Main power cable	Node 12-pin power connector	J36
RPS cable	System board Power Supply Management Interface connector	J42

The following table provides the system board designators that various cables plug into. For more detailed information about system board components, see system board components.

**Table 2** Node Cable connections

Cable	To	System Board Designator
Internal USB connector	Node USB	J69
SATA cable connector	Node SATA1	J57
SATA cable connector	Node SATA2	J58
SATA SGPIO cable	Node SGPIO connector	J39


**Table 3** AC power board connection

Cable	To	System Board Designator
RJ45 cable connector	RJ45 board	J1
UID cable connector	UID LED	J12
Fan connector 1	Fan 1	J7
Fan connector 2	Fan 2	J6
Fan connector 3	Fan 3	J11
Fan connector 4	Fan 4	J10

## Hard Drives

The Server can accommodate up to 4 hard disks drives, 2 in each tray. You can install 4 SAS hard drives or 4 SATA hard drives into the server.

**Figure 4** Hard Drive location




Item	Description
1	SAS/SATA Hard Drive
2	SAS/SATA Hard Drive

To install a Hard Drive:

1. Unlock the HDD carrier latch.
2. Rotate the HDD carrier handle up.
3. Insert the HDD carrier and align the four pins.
4. Rotate the HDD carrier handle down and then lock the HDD carrier latches.


**Figure 5** Installing the hard drive assembly



**To remove hard drive:**

1. Slide the HDD carrier latches to unlock the HDD handle.
2. Raise the HDD handle.
3. Lift the HDD assembly out of the tray.

**Figure 6** Removing the hard drive assembly



**WARNING:** Ensure that the system is powered off and all power sources have been disconnected from the server. Voltages are present at various locations within the server whenever an AC power source is connected. This voltage is present even when the main power switch is in the off position.

# System Board Configuration


## Processor

HP ProLiant SL160z G6 Server, with 2 nodes, supports four-processor operation. With two processors installed, each node supports boot functions through the processor installed in processor socket 1. However, if processor 1 fails, the system automatically boots from processor 2 and provides a processor failure message.

The processor socket supports Quad-Core Intel®Nehalem 5500 Series processor and Intel®Xeon® 5600 Series processor.

**⚠ CAUTION:** It is recommended to use processors of same speeds or cache sizes to prevent possible server malfunction.

**Figure 7** Processor locations



Item	Description
1	Processor 1
2	Processor 2

**⚠ WARNING:** To reduce the risk of personal injury from hot surfaces, allow the heat sink and the processor to cool before touching them.


### To remove the heat sink:

**⚠ CAUTION:** To prevent the heat sink from tilting to one side during installation and removal procedures, use a diagonally opposite pattern (an “X” pattern) when loosening and tightening the two spring-loaded screws. Do not over tighten the heat sink’s spring-loaded screws to prevent them from breaking off. A maximum torque of 4 in-lb is set for the system.

1. Loosen the two mounting pins.
2. Lift the heat sink away from the system board.
3. Lift the heat sink frame away from the system board.

**⚠ CAUTION:** Place heat sink down in an upright position with the thermal patch facing upward. Do not let the thermal patch touch the work surface.

**Figure 8** Removing the Heat Sink assembly




**📌 IMPORTANT:** If the heat sink has been removed for any reason on a previously installed processor, it is critical that you apply more thermal interface material to the integrated heat spreader on the processor to ensure proper thermal bonding between the processor and the heat sink.

**To remove a processor:**


1. Open the processor locking lever and the processor socket retaining bracket.

**Figure 9** Opening the processor socket retaining bracket




2. Using the processor removal tool, remove the processor from the system board:
  - a. Line up the processor tool, ensuring the locking lever graphic on the tool is correctly oriented.
  - b. Press in on the plastic tabs, and then place the tool on the processor.
  - c. Release the tabs, and then carefully lift the processor and tool straight up.

**Figure 10** Removing the processor



3. Carefully rotate the tool, and then push in and release the tabs to secure the processor in the tool.

**Figure 11** Securing the processor




**△ CAUTION:** To avoid damage to the processor, do not touch the bottom of the processor, especially the contact area.

**To install the new processor:**


1. Carefully insert the processor into the processor installation tool. Handle the processor by the edges only, and do not touch the bottom of the processor, especially the contact area.

**Figure 12** Inserting the processor



2. Be sure the tool is oriented correctly. Align the processor installation tool with the socket, and then install the processor. **THE PINS ON THE SYSTEM BOARD ARE VERY FRAGILE AND EASILY DAMAGED.**

**Figure 13** Installing the processor




---

**⚠ CAUTION: THE PINS ON THE SYSTEM BOARD ARE VERY FRAGILE AND EASILY DAMAGED.** To avoid damage to the system board:

- Never install or remove a processor without using the processor installation tool.
- Do not touch the processor socket contacts.
- Do not tilt or slide the processor when lowering the processor into the socket.

- 
3. Press and hold the tabs on the processor installation tool to separate it from the processor, and then remove the tool.


**Figure 14** Removing the processor installation tool



4. Close the processor socket retaining bracket and the processor locking lever.

**CAUTION:** Be sure to close the processor socket retaining bracket before closing the processor locking lever. The lever should close without resistance. Forcing the lever closed can damage the processor and socket, requiring system board replacement.

**Figure 15** Closing the processor socket retaining bracket



**CAUTION:** To allow heat sink to draw as much heat as possible from the processor base, there must be good contact between the heat sink base and the top of the processor. To ensure good contact, you must apply thermal interface material.


**To apply the thermal grease compound:**

1. Use a clean cloth dipped in rubbing alcohol to clean the contact surface on the heat sink and on the new processor. Wipe the contact surfaces several times to make sure that no particles or dust contaminants are evident.
2. Apply the thermal grease compound to the CPU contact surface.

**△ CAUTION:** HP recommends using Shin-Etsu X-23-7783D thermal grease compound for your ProLiant server.

3. Apply all the grease to the top of the processor in the following pattern to insure even distribution.

**Figure 16** Applying grease



**△ CAUTION:** Applying too much grease creates a gap between the contact surfaces, significantly reducing the ability of the heat sink to draw out heat. Installing the heat sink with excessive grease can also cause the grease to spread over the processor pins or the system board base, which can cause electrical shorts that damage the system.


**To install the heat sink:**

**△ CAUTION:** To prevent overheating or a possible system crash, use only a heat sink model specified for the HP ProLiant SL160z G6 server.

1. Put the heat sink frame on the CPU socket.
2. Properly align the heat sink mounting pins to the system board mounting holes.
3. Tighten the mounting pins clockwise to secure the heat sink connection to the system board.

**△ CAUTION:** To prevent the heat sink from tilting to one side during installation and removal procedures, use a diagonally opposite pattern (an "X" pattern) when loosening and tightening the two spring-loaded screws. Do not over tighten the heat sink's spring-loaded screws to prevent them from breaking off. A maximum torque of 4 in-lb is set for the system.

**Figure 17** Installing the heat sink




## Memory

HP ProLiant SL160z G6 server has thirty-two DIMM slots that support up to 256 GB maximum system memory.

You must adhere to the following guidelines when adding or replacing memory modules:

- For 4P system, both physical processors in each node must be of the same type and speed.
- Use 1066/1333 MHz Registered/Unbuffered ECC DDR3 Memory.
- Supported DIMM: 512Mb, 1 GB, 2 GB, 4GB and 8GB (256GB maximum capacity) DDR3


**Figure 18** DIMM slots



### To remove memory module:

1. Completely open the holding clips securing the module.
2. Gently pull the memory module upward to remove it from the slot.

**Figure 19** Removing a Memory module




**CAUTION:** Place the memory module on a static-dissipating work surface or inside of an anti-static bag.

**To install a memory module:**

1. Align the notch on the bottom edge of the module with the keyed surface of the DIMM slot and then press the module fully into the slot.
2. Firmly press the holding clips inward to secure the memory module in place.

**Figure 20** Installing a Memory module



**CAUTION:** The memory slots are structured to ensure proper installation. If you insert a memory module but it does not fit easily into the slot, you may have inserted it incorrectly. Double-check the orientation of the module and reinsert. If the holding clips do not close, the module is not inserted correctly.


**NOTE:** The ProLiant SL160z G6 server supports up to 32 memory modules. Install them in the DIMM slots starting from the DIMM 1 slot.

# PCI Expansion Cards

## System Board PCI Expansion Slots


There are one X16 and one X4 PCIe Riser slots on the system boards.

**Figure 21** PCIe expansion slot location on 160 system board




Item	Component Designator	Component	Function
1	PCIe slot	PCIe slot	Supports X16 PCI Riser Cards
2	PCIe slot	PCIe slot	Supports X4 PCI Riser Cards

**Figure 22** PCIe Riser Card X16 Connectors Location



**Figure 23** PCIe Riser Card X4 Connectors Location




- Single-Slot PCIe riser card (x16 slot)

**To remove the PCIe riser card with the bracket:**

1. Loosen the screw securing the riser card bracket to the chassis.
2. Pull the riser card away together with the bracket.


**Figure 24** Removing the PCIe riser card



**To remove the X16 riser card from the bracket:**

1. Remove the two screws securing the riser card to the bracket.
2. Pull the riser card away from the bracket.


**Figure 25** Removing the PCIe riser card



**To install the PCIe X16 riser card to the bracket:**

1. Align the riser card with the bracket.
2. Fasten the two screws to secure the riser card to the bracket.


**Figure 26** Installing PCIe riser card to the bracket



**To install the riser card with the bracket into the motherboard:**

1. Align the riser card connector with the slot on the motherboard and then insert the assembly into the slot.
2. Fasten the screw to secure the bracket to the chassis.

**Figure 27** Installing the PCIe riser card with bracket




- Single-Slot PCIe riser card (x4 slot)

**To remove the PCIe X4 riser card with the cage:**

1. Remove the two screws securing the PCIe X4 riser card cage to the Chassis.
2. Lift the PCIe X4 cage up and away from the Chassis.


**Figure 28** Remove the PCIe X4 Cage



**To remove the PCIe X4 riser card:**

1. Remove the screw that secures the riser card to the cage.
2. Pull the PCIe card out and away from the PCIe X4 cage.


**Figure 29** Removing the Riser Card X4



**To install the PCIe riser card to the cage:**

1. Align the PCIe X4 riser card to the PCIe X4 Cage.
2. Install and tighten the two screws that secure the riser card to the riser card cage.


**Figure 30** Reinstalling the PCIe riser card X4



**To install the PCIe X4 cage:**

1. Align the riser card cage beside the PCIe X4 connector on the main board
2. Install and tighten the two screws to secure the riser card cage to the chassis.


**Figure 31** Reinstalling the PCIe Riser Card X4



**To remove the PCIe card:**

1. Remove the screw that secures the PCIe card.
2. Open the PCIe latch.
3. Pull the PCIe card back and away from the PCIe riser card.
4. Slide the PCIe bracket across the chassis.
5. Close the PCIe latch.


**Figure 32** Removing the PCIe card



**To install the PCIe card:**

1. Open the PCIe latch.
2. Remove PCIe card or blank.
3. Push the PCIe card into riser card connector.
4. Close PCIe latch.
5. Install screws.

**Figure 33** Installing the PCIe card




## System Battery

The server uses nonvolatile memory that requires 2 batteries to retain system information when power is removed.

This 3-volt lithium coin cell battery is located on the system board.

**Figure 34** System battery location



---

**⚠ WARNING:** Note the following reminders when replacing the system battery:

- Replace the battery with the same type as the battery recommended by HP. Use of another battery may present a risk of fire or explosion.
  - A risk of fire and chemical burn exists if the battery is not handled properly. Do not disassemble, crush, puncture, or short external contacts, or expose the battery to temperatures higher than 60°C (140°F).
  - Do not dispose of used battery in water or fire. Dispose of used batteries according to manufacturer's instructions.
- 

**⚠ CAUTION:** Loss of BIOS settings occurs when the battery is removed. You must reconfigure BIOS settings whenever you replace the battery.

---


**NOTE:** If the server no longer automatically displays the correct date and time, you may need to replace the system battery. Under normal usage, battery life is five to ten years.

---

**To replace the system battery:**

1. To release the battery from its holder, squeeze the metal clamp that extends above top of the battery. When the battery pops up, lift it out.
2. To insert the new battery, slide one edge of the replacement battery under the holder's lip with the positive side facing the metal clamp. Push the other edge down until the clamp snaps over the top of the battery.

**Figure 35** Replacing the battery




## System Board Removal and Replacement Procedure

**To remove the system board:**

**Remove the tray with the system board:**

1. Press the tray latch to release the tray handle.
2. Rotate the tray handle to disengage the power connector.
3. Pull the tray assembly out of the chassis.


**Figure 36** Removing the tray with system board



**Remove the system board from the tray:**

1. Remove the nine screws that secure the system board to the tray.
2. Release the system board from the tray.


**Figure 37** Removing the 160 system board from the tray



**To replace the 160 system board:**

1. Put the system board in the chassis. The nine screw holes on the chassis should align with the system board.
2. Fasten the nine screws on the system board to secure the system board to the chassis.


**Figure 38** Reinstalling the 160 system board to the tray



**To replace the tray with system board:**

1. Push the tray assembly into the tray bay until it stops.
2. Rotate the tray handle until the tray latch catches.


**Figure 39** Installing the tray with system board into the chassis



## Power Supply Unit (PSU)

Located on the rear panel of the server power supply is a standard auto ranging 750watt PSU with PFC (power factor correction) function.

**Figure 40** Power supply unit



**⚠ WARNING:** Take note of the following reminders to reduce the risk of personal injury from electric shock hazards and/or damage to the equipment.


- Installation of power supply units should be referred to individuals who are qualified to service server systems and are trained to deal with equipment capable of generating hazardous energy levels.
- DO NOT open the power supply unit. There are no serviceable parts inside it.

### To install the power supply:


1. Remove the power supply blank out of the power cage.
2. Align the power supply cage connector with the open slot of power supply.

3. Slide the power supply into the power supply bay until it snaps into place.

**Figure 41** Installing the Power supply (1)




**Figure 42** Installing the power supply (2)



To remove the power supply:

1. Press the blue colored handle.
2. Slide the power supply out of the power supply cage.
3. Install the power supply blank into the place where power supply was seated.

**Figure 43** Removing the power supply




## System Fan

The server can support either 3 or 4 system fans located at the chassis' rear fan cage. Fan 1 is optional. You can refer to Fan option Installation instructions for details.

The figure below identifies the system fans by their device number and shows their corresponding cable connections.

**Figure 44** System fan connection




Device number	Connector
System fan 1	J6 on the AC power board
System fan 2	J8 on the AC power board
System fan 3	J10 on the AC power board
System fan 4	J11 on the AC power board

A new system fan can be installed to allow the server to operate properly in case a default system fan becomes defective.

**To remove the system fan:**

1. Disconnect the fan cable from its corresponding board connector.
2. Lift the system fan away from the chassis.


**Figure 45** Removing the system fan



**To replace the system fan:**

1. Insert the system fan into the fan bracket.
2. Connect the fan cable to its corresponding board connector.

**Figure 46** Installing the system fan




# Connectors, Switches, and LEDs

This chapter contains illustrations and tables identifying and describing the connectors, switches, buttons, and LED indicators located on the front panel, rear panel, system board and hard drives of the HP ProLiant SL160z G6.

## Connectors and Components

### Front Panel Components

**Figure 47** Front panel components




Item	Description
1a	Tray handle
1b	Tray latch
2	Serial Port
3	Video Port
4	Top: USB 2.0 Port Bottom: USB 2.0 Port
5	Top: NIC Connector Bottom: NIC Connector
6	IPMI Port
7	UID LED/SW
8	PCI blank
9	Health LED

Item	Description
10	Power Button

## Rear panel components


Figure 48 Rear panel components



Item	Description
1	RJ45 port
2	Power supply 2
3	Power supply 1
4	UID LED

# System board components

Figure 49 System board components



Item	Designator	Description
1	J2	Serial Port (COM1)
2	J1	VGA port
3	J8	USB PORT
4	J7	NIC Port
5	J21,J22,J79; J23,J24,J78; J25,J26,J77	MEMORY DIMM CONN
6	SW1	UID BUTTON
7	J90	IPMI CONN
8	J18	PCI-E-X4 LP RISER SLOT
9	J17	PCI-E-X16 FH/FL RISER SLOT A
10	J27	Jumper
11	J29	TPM CONN
12	J31	PCI-E-X4 FH/FL RISER SLOT B

Item	Designator	Description
13	J11	MINI SAS CONN
14	J69	USB4
15	J3	Storage card slot
16	J56	LCD Connector
17	B1	BATTERY
18	J82	PS backplane connector
19	J65	BP I2C CONN
20	J42	FRONT PANEL CONN
21	J67,J68,J70, J62,J71	FAN CONN
22	J64	12V POWER CONN
23	J57,J58	SATA HDD CONN
24	J63	FAN CONN
25	J47,J47,J76: J46,J45,J75: J43,J44,J74	MEMORY DIMM CONN
26	J51	SYSTEM POWER CONN
27	U73	Processor 1 Socket
28	J60	12V POWER CONN
29	U34	Processor 2 Socket

**△ CAUTION: The TPM is not a customer-removable part.**

Any attempt to remove an installed TPM from the system board breaks or disfigures the TPM security rivet. Upon locating a broken or disfigured rivet on an installed TPM, administrators should consider the system compromised and take appropriate measures to ensure the integrity of the system data.

If you suspect a TPM board failure, leave the TPM installed and remove the system board. Contact an HP authorized service provider for a replacement system board and TPM board.

## Jumpers –Password and Chassis ID

Password (J50) and chassis ID (J45) jumpers. **Table 4** describes the jumper settings.

**Table 4** System configuration switch settings

Jumper	Status
J50	1-2, password Reset
J45	1-2, default setting, 2-3 Clear CMOS

# LED Indicators

This section contains illustration and descriptions of internal and external status LED indicators located on the:


- Front panel
- Rear panel

These LED indicators aid in problem diagnosis by indicating the status of system components and operations of the server.

## Front panel LED indicators

The front panel LED indicators allow constant monitoring of basic system functions while the server is operating.

**Figure 50** Health LED Indicator location




**Table 5** Health LED indicator status

Components	Status	Description
Health LED indicator for Node 1	Red(Blinking)	Critical system failure detected
	Amber (Blinking)	System degrade
	Green	System in on and no failure detected
	Off	System is off and there is no failure prior to system power off
Health LED indicator for Node 2	Red(Blinking)	Critical system failure detected
	Amber (Blinking)	System degrade
	Green	System in on and no failure detected

**Table 5** Health LED indicator status

Components	Status	Description
	Off	System is off and there is no failure prior to system power off

**Figure 51** UID LED indicator location




**Table 6** Type table name here

Components	Status	Descriptions
UID LED indicator for Node 1	Blue	Identification
	Blue(Blinking)	System is being remotely managed
	Off	Off
UID LED indicator for Node 2	Blue	Identification
	Blue(Blinking)	System is being remotely managed
	Off	Off

## Power LED Indicator

The power status of the server is indicated by the bicolor LED on the front panel.

**Figure 52** Power LED indicator location




**Table 7** Power/system health LED indicator status

Component	Status	Description
Power LED indicator for Node 1	Steady green	The server is operating normally.
	Steady Amber	The server is system off or in hibernation with A/C power.
	Steady red	Critical event happens to the server. Please refer to SEL for details.
	Off	The server is system off without A/C power.
Power LED indicator for Node 2	Steady green	The server is operating normally.
	Steady Amber	The server is system off or in hibernation with A/C power.
	Steady red	Critical event happens to the server. Please refer to SEL for details.
	Off	The server is system off without A/C power.

## Rear panel LED indicators

The LAN port on the rear panel has two LED indicators that allow monitoring of network activity.

**Figure 53** LAN/LED indicator location



**Table 8** LAN/LED indicator states

Item	Component	Status	Description
1	LAN activity status LED indicator	Flashing green	Ongoing network data activity.
		Off	No network data activity or no connection.
2	LAN network speed LED indicator	Steady green	The LAN connection is using a GbE link.
		Steady amber	The LAN connection is using 10Mbps/100 Mbps link.
		Off	No connection.

---

# Diagnostic tools and Setup Utilities

This chapter provides an overview of the Power-on Self-Test (POST), the POST error messages, and BIOS, SAS and SATA setup utilities.

## BIOS Software

The server uses BIOS to boot up the system. BIOS software is a ROM-based firmware that allows reliability, manageability, and connectivity for server platforms. This software contains a set of programs permanently stored in an EEPROM chipset located on the system board. These programs assist in managing, initializing, and testing the hardware devices installed on the computer.

BIOS software allows you to:

- Perform configuration from the BIOS Setup Utility  
Using the Setup Utility, you can install, configure, and optimize the hardware devices on the system board. In addition, you can set various features such as serial console redirection, PXE boot, and much more.
- Initialize hardware at boot up using POST routines  
During power-on or warm reset, the BIOS perform Power-on Self-Test (POST) routines to test system components, to allocate resource for various hardware devices, and to prepare the system to boot to various operating systems.

## BIOS Setup Utility

The HP server BIOS Setup Utility is used to configure five primary menu selections:

- Main
- Advanced
- Boot
- Security
- Exit

## Accessing the BIOS Setup Utility

1. Turn on the monitor and server.
2. If the server is already turned on, save your data and exit all open applications, then restart the server.
3. When the HP logo is displayed during POST, press F10 into BIOS Setup Utility. If you fail to press F10 before POST is completed, you will need to restart the server.
4. The first page displayed is the Main menu showing the Setup Utility menu bar. Use the left (←) and right (→) arrow keys to move between selections on the menu bar. Use the up (↑) and down (↓) arrow keys to select items within a menu.


# Navigating through the Setup Utility

Use the keys listed in the legend bar on the right of the Setup screen to navigate through the various menu and submenu screens of the Setup Utility. **Table 9** lists these legend keys and their respective functions.

**Table 9** Setup Utility Navigation Keys

Key	Function
← and →	To move between selections on the menu bar.
↑ and ↓	To move the cursor to the field you want. The currently selected field is highlighted. The right side of each menu screen displays a field help panel—Item Specific Help panel. This panel displays the help text for the currently selected field. It updates as you move the cursor to each field.
<+>, <->	To select a value for the currently selected field (only if it is user-configurable). A parameter that is enclosed in square brackets is user-configurable. Grayed-out parameters are not user-configurable for one of the following reasons: <ul style="list-style-type: none"><li>• The field value is auto-configured or auto-detected.</li><li>• The field value is informational only.</li><li>• The field is password-protected.</li></ul>
Enter	To select a field value or display a submenu screen. Displays more option for items marked with ►
Esc	If you press this key: <ul style="list-style-type: none"><li>• On one of the primary menu screens, the Exit menu displays.</li><li>• On a submenu screen, the previous screen displays.</li><li>• When you are making selections from a pop-up menu, the pop-up closes without making a selection.</li></ul>
F1	To bring up the General Help window. The General Help window describes other Setup navigation keys that are not displayed on the legend bar.
F2, F3	To change BIOS Setup Utility screen colours.
F7	Discard any changes you have made.
<Page Up> and <Page Down>	Moves the cursor to the first/last item (each menu), the item will be display highlight.
<Home> and <End>	Moves the cursor to the first/last item (each menu), the item will be display highlight.
F9	To load default system values.
F10	To save changes and close the Setup Utility.

Figure 54 Setup Utility General Help screen




Press **F1** to get the general help message box.

## Setup Utility Menu Bar

The BIOS Setup Utility provides a menu bar with the menu selections. The menu bar choices are described in the topics below.

## Main Menu

Figure 55 Main menu of BIOS Setup Utility




Use this menu to set the system time and date, and configure of the following items:

- View BIOS build date and version.

- View CPU type / CPU speed /CPU physical count information.
- View System memory size.
- View System serial number.
- View MAC address for the embedded NIC.
- Set Server Asset Tag.
- Set system time and date.
- Set boot features:
  - Enable or Disable POST Speed up.
  - Enable or Disable Bootup Num-Lock.
  - Set restore on AC power loss options, such as last state, power off, and power on.
  - If BIOS displays an error message, set POST F1 Prompt for selections, such as delayed, enabled, or disabled.

## Advanced Menu

**Figure 56** Advanced menu of the BIOS Setup Utility 1



**⚠ WARNING:** Incorrect settings may cause the server to malfunction. To correct the settings, press F9 key to restore the default settings.

- **CPU Configuration** –You can use this screen to select options for the CPU Configuration Settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option. A description of the selected item appears on the right side of the screen. The settings are described on the following pages.
- **CPU Bridge Configuration** –You can use this screen to select options for the CPU Bridge Chipset Configuration Settings. Use the up and down <Arrow> keys to select an item. A description of the selected item appears on the right side of the screen. The settings are described on the following pages.
- **SATA Configuration** –You can use this screen to select options for the S-ATA mode settings. Use the up and down <Arrow> keys to select item. Use the <Plus> and <Minus> keys to change the value of the selected option. The settings are described on the following pages.

- **Super IO Configuration**–You can use this screen to select options for the Super I/O settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option. The settings are described on the following pages.
- **USB Configuration** –These items control various USB devices. From the USB configuration screen, press <Enter> to access the submenu for the USB BIOS Support. Use the up and down <Arrow> keys to select an item. Use the <plus>and <minus> keys to change the value of the selected option. The settings are described on the following pages.
- **PCI Configuration** – You can use this screen to configure PCI Device such as Embedded VGA Control, Embedded NIC.
- **PCI Express Configuration** –You can use this screen to configure PCI Device such as Embedded VGA Control, Embedded NIC.
- **IPMI Configuration** –Select this option and press <Enter> to access the submenu. You can use the submenu to view the contents of IPMI .A delay may be noticed when selecting IPMI. This is due to the retrieval of sensor data .In the submenu, use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus>keys to change the value of the selected option.
- **BIOS Serial Console Configuration** –Set this value to allow configuring the serial port.
- **Trusted Computing** –Configure settings related to trusted Computing innovations.

Figure 57 IPMI Configuration menu of the BIOS Setup Utility




- **Set LAN Configuration** –Select Set LAN Configuration in the left frame of the screen to go to the submenu for that item. You can display a submenu about LAN options by highlighting it using the<Arrow> keys. Set LAN Setup options are described in this section. The Set LAN BIOS Setup screen is shown below (When you have a LO100 Device, this item will display).
- **SEL Configuration**- Select SEL Configuration in the left frame of the screen to go to the submenu for that item. Then you can press Enter to enter its submenu. You can display a submenu about SEL Configuration option by highlighting it using the <Arrow> keys.
- **Hardware Health Information**–Select Hardware Health Information in the left frame of the screen and press<enter> to go to the submenu for that item. That will display CPU temperature, ambient temperature, CPU fan speed, system fan speed, chassis fan speed. These items cannot be changed by the user. It accords with the sense of the case. If there is LV CPU and no card in slot1, then System Fan 6 Rotor 1 and System Fan 6 Rotor 2 no display.


- **Watchdog Configuration** –Select Watchdog Configuration in the left frame of the screen and press<enter> to go to the submenu for that item. That will display POST Watchdog Timer Action, BMC Watch Dog Time Out; you can change the default value.
- **Serial Port Configuration** –Select Serial Port Configuration in the left frame of the screen to go to the submenu for that item. Then you can press Enter to enter its submenu. You can display a submenu about Serial Port Configuration option by highlighting it using the <Arrow> keys.

## Security Menu

**Figure 58** Security menu of the BIOS Setup Utility 1



**Figure 59** Security menu of the BIOS Setup Utility 2



Use this menu to configure the following items:

- **Administrator Password** --- Display if an administrator password is Set or Not.


- **Change Admin Password** -- Allows you to access and change all settings in the Setup Utility. The administrator password allows you to configure access for system users.

To set a new administrator password:

1. In the Security screen, select a set password field - **Change Admin Password**, and then press **Enter**.
2. Type a new password in the Enter New Password box.
3. The password may consist of up to six characters. Alphanumeric characters (A-Z, a-z, 0-9) are recommended to avoid system error.
4. Retype the password to verify the first entry, and then press Enter.
5. Press F10 to close the Setup Utility.
6. After setting the password, Setup automatically sets the password check to **Setup**.

## Boot Menu

**Figure 60** Boot menu of the BIOS Setup Utility




Use this menu to configure the boot settings.

- **Boot Setting Configuration** –Sets which options to run during system boot up. Press **Enter** to access the related submenu. For details on the submenu options, see the “Boot Settings Configuration submenu” section.
- **Standard Boot Order** –Specifies the Boot Device Priority sequence.
- **USB Device Boot Priority** – Use this screen to control the latest added USB Functions by setting the item to the desired value.
- **Restore on AC Power Loss** –Set this value to restores previous power state before loss occurred.

## Exit Menu

Figure 61 Exit menu of the BIOS Setup Utility



Use this menu to save changes or discard changes. When you save and exit, the server reboots.

- **Save Changes and Exit** -- Save the changes you have made and exit the BIOS Setup Utility. (You can also press **F10** key.)
- **Discard Changes and Exit** -- Exit the BIOS Setup Utility without saving the changes you have made. (You can also press **Esc** key.)
- **Discard Changes** -- Discard any changes you have made. (You can also press **F7** key.)
- **Restore Default Setting** -- Restore the default settings for all BIOS setup fields.

## BIOS Update

Perform the steps below to update BIOS:

1. Download the Smart Component (SPxxxx.exe) to a directory on your hard drive.
2. Execute (SPxxxx.exe) and followed with direction to complete the steps. "ProLiant Flash Update" interface will appear.
3. Select items which need to execute:
  - Create a bootable ROMPaq diskette
  - Create a bootable ROMPaq USB Key
  - Create a bootable ROMPaq CD
  - ROMPaq Diskette Flat Files
  - Create a label for the ROMPaq diskette
  - Network ROM Flashing Capabilities
4. Reboot SL160z G6 Server with one of the above bootable devices and make sure the BIOS setting allows booting from the USB disk.
5. Follow the on-screen instructions to finish the flashing of the BIOS.

# Clear CMOS

You may need to clear the Setup configuration values (CMOS) if the configuration has been corrupted, or if incorrect settings made in the Setup Utility have caused error messages to be unreadable.

To clear CMOS:

1. Perform the Pre-Installation Procedure.
2. If necessary, remove any accessory boards or cables that prevent access to the system configuration switch.
3. Locate the system configuration button (J27-A) on the system board.
4. Press the button. AC power must not be connected.
5. Perform the Post-installation instructions.
6. During POST, press F10 to access the Setup Utility.
7. Load setup defaults by pressing F9.
8. Set time, date, and other system values.
9. Press F10 to close the Setup Utility.

---

**NOTE:** Clearing CMOS restore all system configurations and password default settings.

---

# Power-on Self-Test (POST)

Before you can use a server, all devices must be tested and initialized, and the operating system must be bootstrapped to the memory. This is referred to as Power-on Self-Test or POST. POST is a series of diagnostic tests that checks firmware and hardware components on the system to ensure that the server is properly functioning. This diagnostic function automatically runs each time the server is powered on.

These diagnostics, which reside in the BIOS ROM, isolate server-related logic failures and indicate the board or component that you need to replace, as indicated by the error messages. Most server hardware failures will be accurately isolated during POST. The number of tests displayed depends on the configuration of the server.

During POST you can:

- Press **ESC** to skip the HP logo and go to POST boot progress display system summary screen.
- Press **F7** to display the Boot menu.
- Press **F10** to access the Setup Utility.
- Press **F12** to request a network boot (PXE).

# POST Error Indicators

When POST detects a system failure, it displays a POST error message.

# POST Errors Message Definition

Whenever a non-fatal error occurs during POST, an error message describing the problem appears onscreen. These error messages are displayed in normal video (white text on black background), and show the details of the error. The following is an example of a POST error message:

```
012 --- CMOS Date/Time not set
```

**Table 10** lists the most common POST error messages with their corresponding troubleshooting recommendation.

**Table 10** POST error message

601	Error: BMC Not Responding
605	BMC Has Detected Fatal Hardware Error
611	Internal User Area Of BMC FRU Corrupted
612	Controller Update 'boot block' Firmware Corrupted
613	Controller Operational Firmware Corrupted
620	Non-Redundant Fan Failure or Missing
621	Redundant Fan Configuration, One Fan Failure or Missing
622	Redundant Fan Configuration, Multiple Fans Failure or Missing
623	Temperature Violation Detected  Waiting 5 minutes for system to cool Press ESC Key to resume booting without waiting for the system to cool Warning: Pressing ESC is NOT recommended as the system may shutdown unexpectedly
624	Power Supply Failure or Power Supply Unplugged
626	Update SDRR/Configuration Image failed
627	Invalid or Unknown SKU/Chassis ID  Please check Front panel, System ID Jumper or Riser card Press F1 to Continue
628	Redundant Power Supply Mismatch
194	CPUID, Processor family are different
192	L3 cache size mismatch
197	Processor speeds mismatched
198	Processor QPI speed mismatch detected.
193	CPUID, Processor stepping are different
196	CPUID, Processor Model are different
195	Front side bus mismatch. System halted.
160	Processor missing microcode
005	CMOS Checksum Bad
041	Display memory test failed

**Table 10** POST error message

601	Error: BMC Not Responding
040	Refresh timer test failed
048	Password check failed
00B	CMOS Memory Size Wrong
010	Floppy Controller Failure
00C	RAM R/W test failed
003	CMOS Battery Low
701	Insufficient Runtime space for MPS data. System may operate in PIC or Non-MPS mode.
702	No enough APIC ID in range 0-0Fh can be assigned to IO APICs. (Re-assigning CPUs' local APIC ID may solve this issue) MPS Table is not built! System may operate in PIC or Non-MPS mode.
120	\$A0CCMOS Cleared by Jumper. Restore the Jumper and Continue.
122	\$A0CPassword Cleared By Jumper. Restore the Jumper and Continue.

## POST Related Troubleshooting

Perform the following procedures when POST fails to run, displays error messages, or emits beep codes.

If the POST failure is during a routine boot up, check the following:

- All external cables and power cables should be firmly plugged in.
- The power outlet to the server should be connected and works correctly.
- The server and monitor are both turned on. The bicolour status LED indicator on the front panel must be lit up green.
- The monitor's contrast and brightness settings are correct.
- All internal cables are properly connected and all boards firmly seated.
- The processor is fully seated in its socket on the system board.
- The cooler assembly is properly installed on top of the processor.
- All memory modules are properly installed.
- If you have installed a PCI accessory board, verify that the board is firmly seated and any switches or jumpers on the board are properly set. Refer to the documentation provided with the accessory board.
- All internal cabling and connections are in their proper order.
- If you have changed any switches on the system board, verify that each is properly set.

# Physical and Operating Specifications

This chapter provides physical and operating specifications for the HP ProLiant SL160z G6 server. Specifications include:

## System Unit

**Table 11** Hardware Specifications

Item	Components
Processor socket	Intel 1366pin FCLGA
Processor support	Quad-Core Intel® Nehalem 5500 Series processor Intel®Xeon® 5600 Series processor.
Chipset	Intel® Tylersburg 36D /Intel ICH10R
Hardware monitoring device	IPMI 2.0 compliant with Server Engine Pilot II
Gigabit Ethernet controller	Intel 82576
Memory controller	Intel®Tylersburg36D
SATA and IDE controllers	Intel ICH10R
Embedded video controller	ServerEngines VGA core integrated into Pilot II
I/O subsystem	<ul style="list-style-type: none"><li>• PCIE x24 links slot. For</li><li>• X16 PCIE 1U riser</li><li>• X16,x4,x4 2U riser</li><li>• X8,x8,x8 2U riser</li><li>• X16,x8 2U riser</li></ul>
Memory	Six REG DDR3 800/1066/1333 MHz DIMM slots with ECC, Support RDIMM and UDIMM
Default media storage	SAS/SATA hard drive
Optional media storage	<ul style="list-style-type: none"><li>• Eight bays hot-plug LFF HDD cage for SAS or SATA drives.</li><li>• Twelve bays hot-plug LFF HDD cage for SAS or SATA drives.</li><li>• Sixteen bays hot-plug SFF HDD cage for SAS or SATA drives.</li><li>• 24 bays hot-plug SFF HDD cage for SAS or SATA drives.</li></ul>
I/O ports	USB 2.0 ports (two rearmounted ports one internal connector on the system board), video port, serial port and two GbE port

**Table 11** Hardware Specifications

Item	Components
Status LED indicators	
Front panel	<ul style="list-style-type: none"> <li>• Power/system health status</li> <li>• UID status</li> </ul>
Rear Panel	<ul style="list-style-type: none"> <li>• NIC activity</li> <li>• LAN activity</li> <li>• LAN link status</li> <li>• Power/system health status</li> <li>• UID status</li> </ul>
System Board	<ul style="list-style-type: none"> <li>• Auxiliary power indicators</li> </ul>
Power Supply unit (PSU)	750W Redundant, power supply
Thermal solution	Four 80mm system fans

**Table 12** Physical Dimensions

Item	Description
System board platform	ATX (Advanced Technology Extended)
System board dimension	17.935''x6.5''
Server dimensions	
Rack	448W X87.5H X 735.5D (mm)
Server weight	Basic Configuration ( excludes keyboard and monitor): 20 kg

**Table 13** Environmental Specifications

Item	Description
Temperature:	
Operating	+10 to +35° (+50 to +95°F)
Non-operating	-30 to 60° (-22 to 140°F)
Storage	-30 to 60° (-22 to 140°F)
Wet-bulb temperature	38.7° (101.7°F)
Relative humidity:	
Operating	10% to 90% (non-condensing)
Non-operating	5% to 95%
Storage	5% to 95%
Altitude:	
Operating	0 to 3049 meters (0 to 10,000 ft)
Non-operating	0 to 9146 meters (0 to 30,000 ft)

**Table 13** Environmental Specifications

Item	Description
Thermal output (maximum operating)	392 W/hr
Acoustic emissions	LWad: 6.7 Bels
Normal configuration	(operating at room temperature)
	LWad: 6.7 Bels
	(Idle at room temperature)

**Table 14** Hot-Plug Power Supply Specifications

Item	Description
Dimensions (H x W x D)	38.48 mm x 86.36 mm x 190.52 mm
Weight (approximate)	1.1 kg
Input requirements:	
Rated input voltage	90 VAC to 264 VAC
Normal line voltage	100 VAC to 120 VAC /200 VAC to 240 VAC
Line frequency	50Hz – 60Hz
Rated input current	Max: 10A
BTU rating	N/A
Power supply output power:	
Rated steady state power	460W /750W/1200wW
Maximum peak power	N/A
Temperature range:	
Operating	+5° to +50°
Storage/Shipping	-40° to +85°
Relative humidity:	
Operating	5% to 95% relative humidity, non-condensing.
Non-operating	5% to 95% relative humidity, non-condensing

---

# Index

## A

- AC power
  - power-down procedures, 28

## B

- battery
  - replacement warnings, 50
- BIOS Setup Utility
  - accessing, 65
  - additional navigation keys, 66
  - menu bar, 65

- BIOS software
  - Overview, 65

## C

- cable management, 29
- CSR (customer self repair), 5
- customer self repair (CSR), 5

## D

- Diagnostic tools and Setup Utilities
  - BIOS Setup Utility, 65
  - BIOS software, 65
  - BIOS update, 72
  - clear CMOS, 73
  - POST, 73

- drives
  - cable management, 29
  - hard drives, 32

## E

- eATX
  - removing, 51
- electric shock
  - symbol, 27
  - warning, 26

## F

- front panel components, 57

## H

- hard drive
  - removing, 33
- hardware configuration

- hard drives, 32
- memory, 41
- PCI expansion cards, 43
- power supply unit, 53
- processor, 34
- references, 25
- system battery, 49
- system fan, 55
- top cover, 28

- Hardware configuration tools, 25

- hardware specifications

- I/O ports, 76
- LAN controller, 76
- memory, 76
- power supply unit, 77
- processor socket, 76
- processor support, 76
- status LED indicators, 77
- thermal solution, 77

- Hardware Specifications

- chipset, 76
- default media storage, 76
- Hardware monitoring device, 76
- I/O subsystem, 76
- optional storage, 76

- hazardous conditions. *See* symbols on equipment

- hazardous energy circuits
  - symbol, 27

- heat sink
  - installing, 40
  - removing, 34

- hot surface
  - symbol, 27
  - warning, 26

## HP

- authorized reseller, 24
- contact information, 24
- technical support, 24
- technical support requirements, 24

- I
  - improper airflow
    - caution, 26
- L
  - LAN controller, 76
  - LED indicators
    - LAN, 63
    - Power/system health, 62
- M
  - memory controller, 76
  - Memory Module
    - spare part number, 20
  - memory modules
    - guidelines for installation, 41
    - installing, 42
    - removing, 41
- O
  - onboard controllers
    - LAN, 76
    - memory controller, 76
    - storage controller, 76
- P
  - PCIe card
    - installing, 49
    - removing, 48
  - PCIe riser card X4
    - installing, 47
    - removing, 47
  - PCIe X16 cage
    - installing, 46
  - PCIe X4 cage
    - installing, 48
    - removing, 46
  - physical dimensions
    - server, 77
    - system board, 77
  - power supply
    - replacing, 53
  - Power supply blank
    - spare part number, 16
  - Power supply cage
    - spare part number, 16
  - power supply unit. *See* PSU
  - Power/system health LED indicator, 62
  - Power-On Self Test
    - POST error indicators, 73
    - POST related troubleshooting, 75
    - recoverable POST errors, 74
  - processor
    - applying thermal grease, 40
    - installing, 40
    - removing, 36
  - Processor heat sink
    - spare part number, 21
  - processor socket
    - specification, 76
  - Processors
    - spare part number, 20
  - PSU
    - removing, 53
    - replacement warnings, 53
    - type, 77
- R
  - Rail kit left
    - spare part number, 16
  - Rail kit right
    - spare part number, 16
  - rear panel components, 58
- S
  - server dimensions
    - rack, 77
  - server warnings and cautions, 26
  - storage controller, 76
  - symbols on equipment, 27
  - system battery
    - replacing, 50
  - system board
    - dimensions, 77
    - platform, 77
  - System board
    - removing, 51
    - replacing, 52
  - system covers
    - top cover, 28
  - system fan
    - removing, 56
    - replacing, 56
  - system LEDs. *See* status LEDs
  - system structure

- front panel, 57
- rear panel, 58
- System Unit
  - specifications, 76

## T

- thermal solution, 77
- top cover
  - reinstalling, 29
  - removing, 28
- Top cover

- spare part number, 16
- Tray with system board
  - removing, 51
  - replacing, 52

## W

- warnings
  - battery replacement, 50
  - PSU replacement, 53
- warranty, 5