# enovo-

## Lenovo V145-14AST / V145-15AST User Guide

#### Notes

- Before using the product, be sure to read *Lenovo Safety and General Information Guide* first.
- The latest *Safety and Warranty Guide, Setup Guide,* and *Regulatory Notice* are available on the Lenovo Support Web site at: <a href="https://support.lenovo.com">https://support.lenovo.com</a>.
- The latest electronic compliance information and environmental declarations are available from the Lenovo compliance information Web sites.
  - To view compliance information, go to: <a href="https://www.lenovo.com/compliance">https://www.lenovo.com/compliance</a>.
  - To download environmental information, go to: <a href="https://www.lenovo.com/ecodeclaration">https://www.lenovo.com/ecodeclaration</a>.
- Some instructions in this guide may assume that you are using Windows® 10. If you are using another Windows operating system, some operations may be slightly different. If you are using other operating systems, some operations may not apply to you.
- The features described in this guide are common to most models. Some features may not be available on your computer or your computer may include features that are not described in this user guide.
- Microsoft® makes periodic feature changes to the Windows operating system through Windows Update. As a result, some information in this guide may become outdated. Refer to Microsoft resources for the latest information.
- The illustrations in this manual may differ from the actual product. Please refer to the actual product.

#### Second Edition (May 2019)

© Copyright Lenovo 2019.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

# Lenovo

## User Guide

Instructions and technical information in this manual are applicable to the following Lenovo notebook computers unless otherwise stated.

Model name	MT
Lenovo V145-14AST	81MS
Lenovo V145-15AST	81MT

## **Contents**

Chapter 1. Getting to know your computer	1
Top view	1
Left-side view	4
Right-side view	5
Bottom view	
Status indicators	
Chapter 2. Starting to use your computer	9
Microsoft resources for Windows	
Windows 10 desktop components	
Putting the computer to sleep or shutting it down	
Connecting to the Internet	
Using the keyboard	
Connecting USB device	
Chapter 3. Recovering or restoring Windows	
Restoring from a system restore point	
Resetting your computer	
Using a recovery drive to restore or recover Windows	23
Chapter 4. Troubleshooting	24
Display problems	
Sleep problems	
Battery pack problems	
Sound problems	
Other problems	
Trademarke	20

#### ■ Top view




Figure 1. Top view - Lenovo V145-14AST




Figure 2. Top view - Lenovo V145-15AST

**Note:** The dashed areas indicate parts that are not visible externally.

#### • Attention:

• Do *not* open the display panel beyond 180 degrees. When closing the display panel, be careful *not* to leave pens or any other objects between the display panel and the keyboard. Otherwise, the display panel may be damaged.

1	Integrated camera	The integrated camera can be used for video conferencing.	
2	Built-in microphone	Capture sound for video conferencing, voice narration, or audio recording.	
3	Computer display	The LCD display with LED backlight provides brilliant visual output.	
4	Wireless LAN antennas	The wireless antennas are connected with the built-in wireless adapter to send and receive wireless radio signals.	
5	Ventilation slots	Dissipate internal heat.	
6	Power button	Press this button to turn on the computer. When Windows is running, press the Power button to put the computer into sleep mode.	
7	Numeric keypad	For details, see "Numeric keypad (Lenovo V145-15AST)" on page 15. $$	
8	Touch pad	The touch pad functions as a conventional mouse.	
		One piece multi-touch ClickPad: To move the pointer on the screen, slide your fingertip over the pad in the direction in which you want the pointer to move.  Left-click area: Clicking in this area corresponds to the functions of clicking the left button on a conventional mouse. Right-click area: Clicking in this area corresponds to the functions of clicking the right button on a conventional mouse.	
	<b>Note:</b> You can enable/disable the touch pad by pressing F6 $(\mathbb{F}_n)$ .		

#### ■■ Left-side view




Figure 3. Left-side view - Lenovo V145-14AST / Lenovo V145-15AST

- **ac power adapter** Connects to the ac power adapter. **connector**
- **2 RJ-45 connector** Connects the computer to an Ethernet network.

Note: For details, see "Connecting network cables" on page 13.

- **B HDMI connector** Connects to devices with HDMI input such as a TV or an external display.
- 4 USB 3.0 Connect to USB devices.

Note: For details, see "Connecting USB device" on page 18.

**5 Combo audio** Connects to headsets. **connector** 

#### Notes:

- The combo audio connector does not support conventional microphones.
- The recording function might not be supported if third-party headphones or headsets are connected, due to different industry standards.
- **6 Novo button** When the computer is off, press this button to start the recovery system or the BIOS setup utility, or to enter the boot menu.

**Note:** For details, see "Chapter 3. Recovering or restoring Windows" on page 20.

**Memory card slot** Accepts memory cards (not supplied).

**Note:** For details, see "Using memory cards (not supplied)" on page 19.

#### ■ Right-side view




Figure 4. Right-side view - Lenovo V145-14AST / Lenovo V145-15AST

- 1 Optical drive Reads/burns optical discs. (on select models)
- **EXECUTE EXECUTE EXEC**

Note: Lock is not supplied. When purchasing a lock, choose one that utilizes the Cleat<sup>™</sup> locking mechanism and verify its compatibility with the slot before purchase. A lock utilizing the T-Bar<sup>™</sup> locking mechanism is not compatible with the Kensington mini security slot.

#### Bottom view




Figure 5. Bottom view - Lenovo V145-14AST / Lenovo V145-15AST

**1 Ventilation slots** Dissipate internal heat.

**Note:** Make sure that none of the ventilation slots are blocked, or else overheating of the computer may occur.

**2 Speakers** Provide audio output.

#### ■ Status indicators

This section helps you locate and identify the various status indicators on your computer.




Figure 6. Indicators - Lenovo V145-14AST / Lenovo V145-15AST

**1 Camera status** When this indicator is on, the camera is in use. **indicator** 

## Battery/Charging status indicator

AC power adapter status	Indicator status	Meaning
Disconnected	Off	The computer is in sleep mode or turned off; The battery has more than 20% charge.
	Solid amber	The battery has between 5% and 20% charge.
	Fast blinking amber	The battery has between 1% and 5% charge.
	Slow blinking amber	The battery is being charged. When battery charge reaches 20%, the blinking color changes to white.
Connected	Slow blinking white	The battery has between 20% and 80% charge and is still charging. When the battery reaches 80% charge the light will stop blinking.
	Solid white	The battery has more than 80% charge, charging will continue until the battery is fully charged.

## 3 Power status indicator

Indicator	Indicator status	Meaning
Devices etative	On (solid white)	The computer is powered on.
Power status indicator	Blinking	The computer is in sleep mode.
dioatoi	Off	The computer is powered off.

4 Caps Lock Windicator dir

When this indicator is on, you can type uppercase letters directly.

#### ■ Microsoft resources for Windows

Microsoft provides a comprehensive set of information about Windows.

- The preinstalled **Tips** app provides new features and tips for Windows. You can start the **Tips** app by typing "Tips" in the search box of your Windows desktop and selecting the matching results.
- The preinstalled **Get Help** app provides support and assistance for using Windows. You can start the **Get Help** app by typing "Get Help" in the search box of your Windows desktop and selecting the matching result. You must be connected to the Internet to use the **Get Help** app.
- The Microsoft support Web site <a href="https://support.microsoft.com/">https://support.microsoft.com/</a> provides comprehensive helpful information about Windows.

#### Windows 10 desktop components



Figure 7. Windows 10 desktop - Lenovo V145-14AST / Lenovo V145-15AST

- 1 Settings button ② 2 Power button ③
- 3 Start button 

  4 Search box 

  ✓
- 5 Task view button 🖹 6 Battery status icon 🗗
- 7 Wireless status icon 🌠 🌠 🤁 8 Action center 🔲

#### **Settings button**

Settings lets you perform basic tasks. You can also search for more settings using the settings search box.

#### **Battery status icon**

You can move your pointer to this icon to check the battery status. The battery status icon displays the percentage of battery power remaining and how long you can use your computer before you must charge the battery.

#### Wireless status icon

This icon shows the status of your computer's wireless connection.

- \* Your computer is not connected to any wireless network.
- Wour computer is connected to a wireless network.
- Airplane mode is on.

#### **Action center**

Here you can find important notifications from Windows and your apps. You can also change common settings quickly.

#### Putting the computer to sleep or shutting it down

When you have finished working with your computer, you can put it to sleep or shut it down.

#### Putting your computer to sleep

When the computer is in sleep mode, you can quickly wake it to resume use, bypassing the startup process.

To put the computer to sleep, do one of the following:

- Close the display lid.
- Press and hold the power button for 1 second.
- Move the cursor to the lower-left corner, and then select the Start button.
   Select Power → Sleep.

**Note:** Put your computer to sleep before you move it. Moving your computer while the hard disk drive is spinning can damage the hard disk, causing loss of data.

To wake up the computer, do one of the following:

- Press any key on the keyboard.
- Press the power button.

#### Shutting down the computer

If you are not going to use your computer for a long time, shut it down. To shut down your computer, do one of the following:

- Move the cursor to the lower-left corner, and then select the Start button.
   Select Power → Shut down.
- Right-click the Start button in the lower-left corner and select Shut down or sign out → Shut down.

#### Connecting to the Internet

You can connect your computer to the Internet either by network cables or Wi-Fi network.

#### Connecting network cables

To insert a network cable, do the following:

- Hold one connector of the network cable to press the RJ-45 cover down gently ■.
- 2 Insert the connector into the RJ-45 connector 2.




Figure 8. Connecting network cables - Lenovo V145-14AST / Lenovo V145-15AST

#### Software configuration

Consult your Internet Service Provider (ISP) for details on how to configure your computer.

#### ■ Connecting to a Wi-Fi network

Your computer comes with a built-in Wi-Fi network card to help you establish wireless connections and monitor connection status. Wireless connection is the transfer of data using radio waves instead of cables.

**1** Click the wireless icon in the notification area.

**Note:** If the wireless icon is not displayed, airplane mode may be turned on.

- **2** Select the network name you want to connect to and click **Connect**.
- **3** Enter the security key when prompted and click **Next**.

#### ■ Turning on/off airplane mode

- Press **F7** on the keyboard.
- Click Start → Settings → Network & Internet → Airplane mode. Slide the toggle for Airplane mode to turn it on or off.
- In action center, click the **Airplane mode** button to turn it on or off.

#### Using the keyboard

#### Numeric keypad (Lenovo V145-15AST)

The keyboard has a separate numeric keypad. To enable or disable the numeric keypad, press the **Num Lock** key.



Figure 9. Numeric keypad - Lenovo V145-15AST

#### **Hotkeys**

Some keys on the keyboard are printed with symbols. These keys are called hotkeys and can be pressed alone to change certain settings quickly.

**Note:** Some hotkeys share keys with function keys (F1 to F12). If Hotkey mode is set as disabled in the BIOS setup utility, you need to press the Fn key with these hotkeys to access certain settings.



Figure 10. Hotkeys - Lenovo V145-14AST



Figure 11. Hotkeys - Lenovo V145-15AST

Hotkey	Function
M <sub>F1</sub>	Mutes/unmutes the sound.
<b>□</b> F2	Decreases the volume level.
<b>4</b>	Increases the volume level.
× F4	Enables/disables the microphone.

Hotkey	Function
C <sub>F5</sub>	Refreshes the desktop or the currently active window.
<u>□</u> <sub>F6</sub>	Enables/disables the touchpad.
<b>→</b> <sub>F7</sub>	Enables/disables Airplane mode.
S FB	Enables/disables the integrated camera.
<b>□</b> Fθ	Locks the screen.
F10	Toggles the display between the computer and an external display device.
₩- F11	Decreases the display brightness.
Ŭ+ F12	Increases the display brightness.

#### Setting hotkey mode

The **Hotkey Mode** setting in the BIOS setup utility determines whether hotkeys takes precedence over function keys.

- 1 Shut down the computer.
- **②** Press the Novo button and then select **BIOS Setup**.
- **③** In the BIOS setup utility, open the **Configuration** menu, and change the setting of **Hotkey Mode** to **Enabled** or **Disabled**.
- **4** Open the **Exit** menu, and select **Exit Saving Changes**.

#### Connecting USB device

You can connect a USB device to your computer by inserting its USB plug into the USB connector on your computer.




Figure 12. Connecting USB device - Lenovo V145-14AST / Lenovo V145-15AST

The first time you plug a USB device into a particular USB connector on your computer, Windows automatically installs a driver for that device. After the driver has been installed, you can disconnect and reconnect the device without performing any additional steps.

**Note:** Typically, Windows detects a new device after it has been connected, and then installs the driver automatically. However, some devices may require you to install the driver before connecting. Check the documentation provided by the device's manufacturer before connecting the device.

Before disconnecting a USB storage device, make sure your computer has finished transferring data to that device. Click the **Safely Remove Hardware and Eject Media** icon in the Windows notification area to remove the device before disconnecting.

**Note:** If your USB device uses a power cord, connect the device to a power source before connecting it. Otherwise, the device may not be recognized.

#### Using memory cards (not supplied)

Your computer supports the following types of memory cards:

- Secure Digital (SD) card
- Secure Digital High Capacity (SDHC) card
- Secure Digital eXtended Capacity (SDXC) card
- MultiMediaCard (MMC)

#### Notes:

- Insert *only* one card in the slot at a time.
- This card reader does not support SDIO devices (e.g., SDIO Bluetooth, etc.).

#### Inserting a memory card

Insert the memory card until it touches the bottom of the slot.

#### Removing a memory card

Gently pull the memory card out of the memory card slot.

**Note:** Before removing the memory card, disable it by using the Windows safely remove hardware and eject media utility to avoid data corruption.

#### **Chapter 3. Recovering or restoring Windows**

This chapter provides information about the recovery options for Windows 10.

You may need to recover or restore Windows if you encounter the following situations:

- Your computer cannot start properly.
- Your computer does not work well after installing apps, drivers, or updates.

Windows 10 provides several options for you to recover or restore Windows. The following table helps you decide which option to use if you're having problems with your computer.

Problem	Available options
Your computer isn't working well after installing apps, drivers, or updates.	Restore from a system restore point.
Your computer isn't working well and you don't know what is causing the problem.	Reset your computer.
Windows cannot start properly.	Use a recovery drive to recover or restore your computer.
You want to recycle or donate your computer.	Reset your computer.

#### **Chapter 3. Recovering or restoring Windows**

#### Restoring from a system restore point

- In the search box of your Windows desktop, search for Recovery and then select it.
- **2** Select Open System Restore  $\rightarrow$  Next.
- **3** Select a restore point and then select  $Next \rightarrow Finish$ .

**Note:** You may select **Scan for affected programs** to check which program and driver installation is associated with a particular restore point.

#### ■ Windows System Restore

System Restore is a tool included in Windows. It monitors changes to Windows system files and saves system state as a restore point. If your computer does not work properly after installing apps, drivers, or updates, you can revert your system to a previous restore point.

**Note:** Reverting your system to a previous restore point does not affect your personal data.

System Restore creates restore points in three cases:

- automatically when it detects changes to Windows system files
- at regular intervals (if set up by the user)
- at any time by the user

#### Creating a system restore point manually

You can use Windows System Restore to create a restore point at any time.

- In the search box of your Windows desktop, search for **Create a restore point** and then select it.
- **②** Select the **System Protection** tab and then select **Create**.

#### **Chapter 3. Recovering or restoring Windows**

#### ■ Resetting your computer

If your computer isn't working well and you're not sure why, you can reset your computer.

- **1** To reset your computer:
  - When the computer is off, press the Novo button to open the Novo Menu; select System Recovery → Troubleshoot → Reset this PC.
  - In Windows, go to Settings → Update & security → Recovery; under Reset this PC, select Get Started.
- 2 Choose an option.
  - If you want to keep your personal files, select **Keep my files**.
  - Otherwise, select **Remove everything**.

**Note:** If you're planning to donate, recycle, or sell your PC, use this option and choose to fully clean the drive. This might take an hour or two, but it makes it harder for other people to recover files you've removed.

## Using a recovery drive to restore or recover Windows

If Windows cannot start properly, you can use a recovery drive (created in advance) to restore or recover Windows.

- Connect the recovery drive to your computer; restart your computer and set it up to start from the recovery drive.
- **②** On the **Choose an option** screen, select **Troubleshoot**.
- **3** Choose a recovery option.
  - Select Advanced Options → System Restore to restore your computer to a system restore point.
  - Select Recover from a drive.

**Note:** If you did not select the **Back up system files to the recovery drive** option when creating the recovery drive, **Recovery from a drive** is not available.

#### Attention:

• All personal files created on your computer will be deleted after recovering from the drive.

#### Creating a recovery drive

Use a USB drive (not included) to create a recovery drive. You can use it to fix problems with your computer in cases when Windows cannot start properly.

- In the search box of your Windows 10, search for Create a recovery drive and then select it.
- **2** Make sure **Back up system files to the recovery drive** is selected and then select **Next**.
- Sonnect a USB drive to your computer, select it and then select Next → Create.

#### • Attention:

• If there are personal files on the USB drive, back up all personal files before using it to create a recovery drive.

#### • Important:

 When your recovery drive is created, you might see a Delete the recovery partition from your PC option. If you want to free up drive space on your computer, select it and then select Delete. Otherwise, select Finish.

#### **Chapter 4. Troubleshooting**

#### Display problems

When I turn on the computer, nothing appears on the screen.

Make sure that:

- The ac power adapter is connected to the computer and plugged into a working electrical outlet.
- The computer power is on. (Press the power button again for confirmation.)
- The brightness level of the screen is appropriately set.

If these items are correctly set, yet the screen remains blank, have the computer serviced.

- When I turn on the computer, only a white cursor appears on a blank screen.
  - Turn off the computer, and then turn it on again.
  - If the problem persists, restore backed-up files to your Windows
    environment or the entire contents of your hard disk to its original factory
    contents using the Windows recovery system. If you still see only the
    cursor on the screen, have the computer serviced.
- The screen goes blank while the computer is on.

Your screen saver or power management may be enabled. Do one of the following to resume from sleep mode:

- Press any key on the keyboard.
- Press the power button.

The screen is blank.

Do the following:

- If you are using the ac power adapter or the battery pack, and the battery status indicator shows that the battery is not depleted, press **F12** to make the screen brighter.
- If the system status indicator is blinking, press the power button to resume from sleep mode.
- If the problem persists, follow the solution in the next problem "The screen is unreadable or distorted."
- The screen is unreadable or distorted.

Make sure that:

- The screen resolution and color quality are correctly set.
- The monitor type is correct.
- Incorrect characters appear on the screen.

Are the operating system or programs installed correctly? If they are installed and configured correctly, have the computer serviced.

#### **Chapter 4. Troubleshooting**

#### ■ Sleep problems

The critical low-battery error message appears, and the computer immediately turns off.

The battery power is getting low. Connect the ac power adapter to the computer.

The computer enters sleep mode immediately after Power-on self-test (POST).

Make sure that:

- The battery pack is charged.
- The operating temperature is within the acceptable range. See "Chapter 2. Use and care Information" in the *Lenovo Safety and General Information Guide*.

**Note:** If the battery pack is charged and the temperature is within range, have the computer serviced.

- The computer does not resume from sleep mode, and the computer does not work.
  - If your computer is in sleep mode, connect the ac power adapter to the computer and then press the power button.
  - If the system still does not resume from sleep mode, stops responding, or cannot be turned off, reset the computer. Unsaved data may be lost. To reset the computer, press and hold the power button for eight seconds or more. If the computer is still not reset, remove the ac power adapter.

#### Battery pack problems

Battery status icon shows status incorrectly.

Your computer shuts down before the battery status icon shows empty, or your computer continues operating after the battery status icon shows empty.

• Recharge the battery.

#### Sound problems

■ No sound can be heard from the speakers even when the volume is turned up.

Make sure that:

- The Mute function is off.
- The combo audio connector is not being used.
- The speakers are selected as the playback device.

#### **Chapter 4. Troubleshooting**

#### Other problems

- Your computer does not respond.
  - To turn off your computer, press and hold the Power button for eight seconds or more. If the computer still does not respond, remove the ac power adapter.
  - Your computer might lock when it enters sleep mode during a communication operation. Disable the sleep timer when you are working on the network.
    - To disable the sleep timer, click **Start** → **Settings** → **System** → **Power** & **sleep**; under Sleep, select **Never** in the pull down menu.
- A connected external device does not work.
  - Do not connect or disconnect any external device cables other than USB while the computer power is on. Otherwise, you might damage your computer.
  - When using high power consumption external devices such as an external USB optical disk drive, use an external device power adapter. Otherwise, the device may not be recognized, and the system may shut down as a result.

#### **Trademarks**

LENOVO and LENOVO logo are trademarks of Lenovo. Microsoft, Windows and Cortana are trademarks of the Microsoft group of companies. Thunderbolt is a trademark of Intel Corporation or its subsidiaries in the U. S. and/or other countries. The terms HDMI and HDMI High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries. Wi-Fi is a registered trademark of Wi-Fi Alliance. All other trademarks are the property of their respective owners. © 2019 Lenovo.